

Safety instructions



· Presence of live parts inside the device! Do not open. Risk of electricshock!

No parts should be repaired by users.

Place the device on a flat, firm and stable surface. Do not put it on acarpet or rug.

· Place the device in a well-ventilated location to prevent the accumulation of internal heat.

- Protect the device from high temperatures, humidity, water and dust.
- · Do not place any objects near your device that may damage it (e.g.liquid-filled objects or candles).
- Do not mix old and new batteries and Do not mix alkaline, standard (carbon-zinc) or rechargeable (ni-cab,ni-mh,etc.) batteries.

Accessory List

Please open the package and check the following accessories:
















Remote Control Power Adapter User Manual



Hardware Structure


Product Interface Introduction



USB

Remote Control

for what you want.



Note: Press the Google Assistant button to start voice searching

System Connection

- 1. Connect the TV Stick to the HD input port of the TV set
- 2. Connect the TV Sitck to the power supply
- 3. Switch on the TV Stick and connect it to the network via WiFi
- 4. Open any TV or movie you want to see



Bluetooth Pairing Method

- 01 For the first pairing, please place the remote control near the tv stick. Press and hold the [LEFT] and [RIGHT] buttons on the remote control for about 10
- seconds at the same time, and you will see the red light on the remote



Remote Indicator Status

- 01 Infrared status: When infrared is emitted, the LED blinks 2 times
- control constantly fashing, then release it to automatically enter pairing mode. 02 Bluetooth status: When sending Bluetooth, the LED will be on when the
- 02 Second pairing (Bluetooth reconnection), press any button on the remote control to reconnect.



continuously when the key is pressed; the LED goes out when the key is

button is pressed; the LED will be off when the button is pushed up.

Troubleshooting

- No display after power on?
- Confirm your device is connected to the TV well and set the correct HD Input from your TV configuration.
- TV has images but no sound?
- Make sure your TV is not in mute and low volume.
- Fail to connect to the network?
- Make sure the Ethernet cable is properly connected. Make sure Wi-Fi is functional and your tv stick has a strong enough signal from your router.
- Remote control failure?
- Replace the battery of the remote control with a new one, and make sure it is placed in the correct polarity.
- Make sure the remote control is within the range of the tv stick.
- Go to the Setting menu to unpair and re-pair the remote control.
- Please use our accessories to avoid any risk.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio

- frequency energy and, if not installed and used in accordance with the instructions,
- may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
- If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged
- to try to correct the interference by one or more of the following measures:
- -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.
- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.
- Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

CEF© RoHS 🥸 MADE IN CHINA