


5.8G Wireless T&R Instrument



USB charging:

- DC 5V/1A USB. (This is TYPE-C port that connects to the 5V1A adapter)

Pairing key:

- Press and hold for 3 seconds for pairing; Pairing light blinks rapidly. When the pairing is successful, the pairing light will remain on. First Press the pairing key to check the current channel, Then press the key again in 3 seconds to change the channel. During change channels, the indicator status is that all lights are off for 1 second.
- Channel indication
 - Channel 1: LED1 is on;
 - Channel 2: LED1, LED2 on;
 - Channel 3: LED1, LED2, LED3 on;
 - Channel 4: LED1 on, LED2 on, LED3 on, LED4 on;

Power ON-OFF key/Mute:

- This is the hand press type will restore the light touch key.
- Press and hold for 3 seconds for ON/OFF, The light will come on when you turn ON, The lights go out when the machine is turned OFF.
- Press the button for a short time to enter MUTE mode. At this point, the backside pairing light will enter a cycle state of two rapid flashes

Note: This TX is inserted into the transmitter end of the guitar or sound source.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement.


To maintain compliance with FCC's RF exposure guidelines, the distance must be at least 5mm between the radiator and your body, and fully supported by the operating and installation

This device meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. The SAR limit of USA (FCC) is 1.6 W/kg averaged. Device types: 5.8G Wireless Instrument (FCC ID: 2A3BF-RPW001) has also been tested against this SAR limit. SAR information can be viewed on-line at <http://www.fcc.gov/oet/ea/fccid/>. Please use the device FCC ID number for search. This device was tested simulation typical 0mm to body.

To maintain compliance with FCC RF exposure requirements, the use of accessories should maintain a separation distance between the user's bodies mentioned above, the use of accessories should not contain metallic components in its assembly, the use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

5.8G Wireless T&R Instrument

RX Model



USB charging:

- DC 5V/1A USB.

Pairing key:

- Press and hold for 3 seconds for pairing; Pairing light blinks rapidly. When the pairing is successful, the pairing light will remain on. First Press the pairing key to check the current channel, Then press the key again in 3 seconds to change the channel. During change channels, the indicator status is that all lights are off for 1 second.
- Channel indication
- Channel 1: LED1 is on;
- Channel 2: LED1, LED2 on;
- Channel 3: LED1, LED2, LED3 on;
- Channel 4: LED1 on, LED2 on, LED3 on, LED4 on;

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement.

To maintain compliance with FCC's RF exposure guidelines, the distance must be at least 5 mm between the radiator and your body, and fully supported by the operating and installation

Note: The receiver does not have a transmitting function