

## 取扱説明書

S600仕様書

使用前にこのマニュアルをよくお読みください

※本品を一度 Nintendo Switch にペアリングした場合、再度ペアリングの必要はありません。  
※本品がスリーブに入った時、再接続の際は本品のいずれかのボタンを押すだけです。  
(L スティック、R スティックを除く)  
※Switch 本体がスリーブに入った時、本品のホームボタンを押すことによって Switch のスリーブ状態を解除できます。

### 2. 有線接続

※HOMEメニューの「設定」→「コントローラーとセンサー」→「Proコントローラーの有線通信」を「ON」にしてください。

(1) 本品と Switch 本体をケーブルでつなぎ、有線で通信するように設定できます。

1. ケーブルは両端とも Type C のものでなくてはなりません。(ケーブルは「USB-Type C タイプ」である場合、変換用のアダプタを別途購入しなければならない。)

2. 本品と Switch 本体を「ケーブル」でつなぐだけOK。

3. ケーブルでつなぐとすぐに Switch 本体の左上に「登録しました」の表示が出る。

switch-baseのUSB端子

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

→

<div data-bbox="2555 330 2565 340" data-label="

## **FCC Statement**

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.