

ColorFit Ultra 2

Please refer to this manual before using the product

What's in the box

Charging cable x1 ColorFit Ultra 2 Smartwatch x1

Table of Contents

Get Started

- What's in the box
- Charge the watch
- Turn the watch on and off
- Watch Navigation
- Screen Navigation
- Button

Watch Features

- Activity
- Workouts
- SpO2
- Heart Rate
- Sleep
- Breathe
- Weather
- Music
- Reminders
- Stopwatch
- Alarm
- World Clock
- Watch Faces
- Stocks
- Stress
- Flashlight
- Settings
- Cycle Tracker

Charging the ColorFit Ultra 2 Smart Watch

Before using your ColorFit Ultra 2 for the first time, charge the battery to its full capacity. Use the charging cable provided with the watch to charge. On a full charge, ColorFit Ultra 2 can last up to 9 days.

Note: The battery life and time to fully charge your device may vary as per usage and other factors.

To charge ColorFit Ultra 2

- Plug the USB cable into a power adaptor. Plug the power adaptor into an electrical socket (Power adaptor not included).
- Place the magnetic charger on the magnetic charging points of the watch.

General Device Information and Tips

Regulatory and Safety Information

Customer support

Power On

Press and hold the side button for a few seconds to turn on the watch.

Power Off

Press and hold the side button for a few seconds, select Shut down and confirm to power off.

Waking Up the Watch

To preserve battery, the watch screen turns off when not in use. To turn the screen back on, you can wake up the watch by:

- Swiping left or right to access shortcuts.
- Swiping up to go to quick settings menu.
- Swiping down to check your message notifications.

Pressing the side button

Turning on the Wrist sense

Watch Navigation

The ColorFit Ultra 2 smartwatch has a 1.78" AMOLED display touch screen. Navigate the watch by tapping on the screen, swiping side to side, up and down and pressing the side button.

Setup

Before pairing, make sure that your smartphone and smartwatch are next to each other. The app will ask for personal information such as height, weight and sex to calculate your stride length, distance covered, calorie burn rate.

Note: The battery life and time to fully charge your device may vary as per usage and other factors.

Home Screen Navigation

The home screen is the watch face. From the home screen:

- Swipe left or right to access shortcuts.
- Create an account or login using an existing account. Note: Ensure that your smartphone is running on Android 4.4 or iOS 9+ and is connected to mobile data or a Wi-Fi network.

Changing the Watch Face

Give your screen a personalised style by changing or customising the watch face from the NoiseFit app or the watch.

Pair the Watch

In your smartphone, download the NoiseFit app from the Play store or the App store and install it. Create an account or login using an existing account. Note: Ensure that your smartphone is running on Android 4.4 or iOS 9+ and is connected to mobile data or a Wi-Fi network.

On the Watch

Touch and hold the home screen. Swipe up to choose from the watch faces.

Button Navigation

Press the side button to turn on the watch display.

Feed in your personal information and health goals in the app.

Go to 'Pair Device' page in the app, select the watch name and MAC address and link the watch.

You will find the information related to the device here, including device name, Bluetooth version and version.

Scan the QR code from the NoiseFit app on your phone.

Select Pair with device and wait for it to pair.

Watch Features

Watch Face

You can switch between different watch faces in the watch, choose and download default, animated watch faces or create your own watch faces in the NoiseFit app.

Vibration

Set the vibration level per your preference.

Power

Set the power level per your preference.

Smart ON

Choose to turn on Smart ON function. Note: The smart watch will activate once the watch is moved from the wrist.

Always ON

Choose to turn on Always ON function. Note: Choosing to turn on the Always ON display will affect battery life.

QR Code

Scan the QR code to connect with the app.

Device Info

Scan the QR code to connect with the app.

Power off

Scan the QR code to connect with the app.

Reset

Scan the QR code to connect with the app.

Watch Features

Watch Face

You can switch between different watch faces in the watch, choose and download default, animated watch faces or create your own watch faces in the NoiseFit app.

Vibration

Set the vibration level per your preference.

Power

Set the power level per your preference.

Smart ON

Choose to turn on Smart ON function. Note: The smart watch will activate once the watch is moved from the wrist.

Always ON

Choose to turn on Always ON function. Note: Choosing to turn on the Always ON display will affect battery life.

QR Code

Scan the QR code to connect with the app.

Device Info

Scan the QR code to connect with the app.

Power off

Scan the QR code to connect with the app.

Reset

Scan the QR code to connect with the app.

Watch Features

Watch Face

You can switch between different watch faces in the watch, choose and download default, animated watch faces or create your own watch faces in the NoiseFit app.

Vibration

Set the vibration level per your preference.

Power

Set the power level per your preference.

Smart ON

Choose to turn on Smart ON function. Note: The smart watch will activate once the watch is moved from the wrist.

Always ON

Choose to turn on Always ON function. Note: Choosing to turn on the Always ON display will affect battery life.

QR Code

Scan the QR code to connect with the app.

Device Info

Scan the QR code to connect with the app.

Power off

Scan the QR code to connect with the app.

Reset

Scan the QR code to connect with the app.

Watch Features

Watch Face

You can switch between different watch faces in the watch, choose and download default, animated watch faces or create your own watch faces in the NoiseFit app.

Vibration

Set the vibration level per your preference.

Power

Set the power level per your preference.

Smart ON

Choose to turn on Smart ON function. Note: The smart watch will activate once the watch is moved from the wrist.

Always ON

Choose to turn on Always ON function. Note: Choosing to turn on the Always ON display will affect battery life.

QR Code

Scan the QR code to connect with the app.

Device Info

Scan the QR code to connect with the app.

Power off

Scan the QR code to connect with the app.

Reset

Scan the QR code to connect with the app.

Watch Features

Watch Face

You can switch between different watch faces in the watch, choose and download default, animated watch faces or create your own watch faces in the NoiseFit app.

Vibration

Set the vibration level per your preference.

Power

Set the power level per your preference.

Smart ON

Choose to turn on Smart ON function. Note: The smart watch will activate once the watch is moved from the wrist.

Always ON

Choose to turn on Always ON function. Note: Choosing to turn on the Always ON display will affect battery life.

QR Code

Scan the QR code to connect with the app.

Device Info

Scan the QR code to connect with the app.

Power off

Scan the QR code to connect with the app.

Reset

Scan the QR code to connect with the app.

Watch Features

Watch Face

You can switch between different watch faces in the watch, choose and download default, animated watch faces or create your own watch faces in the NoiseFit app.

Vibration

Set the vibration level per your preference.

Power

Set the power level per your preference.

Smart ON

Choose to turn on Smart ON function. Note: The smart watch will activate once the watch is moved from the wrist.

Always ON

Choose to turn on Always ON function. Note: Choosing to turn on the Always ON display will affect battery life.

QR Code

Scan the QR code to connect with the app.

Device Info

Scan the QR code to connect with the app.

Power off

Scan the QR code to connect with the app.

Reset

Scan the QR code to connect with the app.

Watch Features

Watch Face

You can switch between different watch faces in the watch, choose and download default, animated watch faces or create your own watch faces in the NoiseFit app.

Vibration

Set the vibration level per your preference.

Power

Set the power level per your preference.

Smart ON

Choose to turn on Smart ON function. Note: The smart watch will activate once the watch is moved from the wrist.

Always ON

Choose to turn on Always ON function. Note: Choosing to turn on the Always ON display will affect battery life.

QR Code

Scan the QR code to connect with the app.

Device Info

Scan the QR code to connect with the app.

Power off

Scan the QR code to connect with the app.

Reset

Scan the QR code to connect with the app.

Watch Features

<div