


INSTRUCTION OF BUTTONS

- **M11 audio buttons**



Play / Pause Stop

Long press: On and Off



Next song

Long press: Vol down



Prev song

Long press: Vol up

- **LED lamp working instruction**

Wireless: **wireless** is preferred when starting up. Blue LED flash represents waiting for connection, while slow flash indicates successful connection.

Voice speakerphone: in **wireless** mode, **short press on / off to answer / hang up & long press on / off to reject call.**

Charging: in the charging state, **the red LED indicates charging in progress and will turn off once fully charged.**

- **How to play music**

Push on/off button to turn on the speaker, it will enter pair mode with blue LED flashing quickly, turn on **wireless** of your mobile select "M11" to pair. Pairing is successful when the blue led flashing comes slowly and there is a voice prompt, you can enjoy music now.

- **TWS matching guidelines**

1. Turn on two "M11";
2. When the speaker is not connected to bluetooth, double-click the "play" key (with prompt tone) of one "M11" to launch the host search function
3. This platform "M11" will be used as the host to actively search for "M11" products with TWS function around and automatically match
4. At this time, "M11" will automatically allocate the left and right sound channels to be used as the stereo wireless pair box.
5. Turn on the **wireless** of the mobile phone, search the **wireless** name "M11" and click the connection.
6. The next time you start the machine, the two "M11" that have been successfully paired will automatically connect. If you want to unpair, just double-click the "play" Key on either of them"

- **Basic parameters**

Speaker type: **wireless** speaker

Active passive: passive

Adjustment: key

Features: wireless connection, hands-free call, voice prompt,

Power supply: built-in 500Mah polymer lithium battery, dc 3.7v-810mA

- **Technical parameters**

The speaker unit: 1.2 inch 4 Ω

Output power: 3W

Wireless transmission range: < 10M (no obstacle)

Frequency range: 100hz-20khz

Product specification: Length 7.5CM; width 8.5CM; height 7CM

Net weight: 109g

SP-M11 MINI AUDIO



FCC Caution.

(1) § 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

§ 15.21 Changes or modification warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

§ 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.