

MagiLcous

RGB Floor Lamp
Music Sync




FX100
User Manual

CONTENTS

- 1 Product Specifications
- 1 Product Parameter
- 2 How to assemble
- 4 Manual Control by 3 Buttons
- 5 APP Control
- 7 FCC Compliance

Product Specifications




Product Parameter

Model	FX100
Adapter Input	AC100-240V 50/60Hz
Adapter Output	DC12V ==1A
Power	Max 12W
LEDs	87pcs SMD 5050 RGB
Product Size	D180mm * H1600mm
Control Mode	App Control
Product Weight	1700g

How to assemble

1. Lamp assembly


 Please do not disassemble or assemble the lamp when it is on.




- 1 Screw the lamp-socket and the threaded lamp tube together. When rotating, hold the lamp-socket, rotate the chassis and tighten them.
- 2 Insert the lamp tube, pay attention to the male and female head, and insert it tightly without gap.
- 3 Insert the lamp tube, pay attention to the male and female head, and the insert firmly without gap.
- 4 Insert the fourth section. Note that this is the top section with an end cap.

2. Power control assembly

- 1 Connect the lamp body to the connector of the controller.
- 2 Insert the DC head of the power output into the controller interface.
- 3 Insert the power plug into the AC power socket.



Manual Control by 3 Buttons




C : Click to switch 10 kinds of scene modes.

O OFF/ON: click to turn on or off the light, long press for 5S to enter the red light blinking, pairing of the mobileto realize APP control.

M : Click to switch between 4 music modes.

Remote Control



APP Control



1. Download Smart Life App from Apple App Store or Google Play.
2. App Control Supports Android 5.0 and IOS 10.0.


Note

1. App share function, when the main sharing account is not within the connection range or closed during the phone call, the sharing account is able to control the device;
2. If the product is stuck, please turn off the power and restart it. Resetting the device after booting can fix this type of problem.

1 Open the mobile Smart Life APP, click to add a device.




2 Automatically discover the music atmosphere light.



3 Check the music atmosphere light and click Next.



4 The distribution network is completed.



FCC Compliance

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must withstand any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Manufacturer : Shenzhen Guiyang Network Technology Co., Ltd
Address : 1404K3, East Block, Shengtang Commercial Building,
Tairan 9th Road, Tianan Community, Shatou Street, Futian District,
Shenzhen, China.



Made in China