


Thinker Connect Getting Started

- 01 Components for Setup
- 02 Installation
- 03 Connectivity
- 04 Setting Up
- 05 Stylus

Components for Setup


In the box

Thinker Connect
2.5m Micro USB to USB Type A Cable
1m Power Cable
Power Adapter
Stylus with Charging Cables



Not in the box


HDMI Cable Measuring Tape Marker Display Panel Computer



Basic Guidelines

Take care not to place the panel in direct sunlight.


For seamless experience the display panel has to be mounted firmly. If needed, add some extra padding (ex: sponge) for support between the panel and the wall to prevent it from shaking while writing.




Measure and mark the centre and top list of the display. Place Thinker Connect on the display and use the clip to fix it safely on the display. Make sure Thinker Connect is not leaning forward or falling behind.











Connectivity

03

Port Description





Setting Up

04

Installing Drivers

Go on: airmind.ai/downloads and download

EyeRIS Drivers

Flow Software

Run the downloaded files, setup window will guide you to Install the softwares

Calibration


Launch EyeRIS drivers and click on


Auto Calibration





Calibration continued...






Stylus

05

Description



Charging

Note: Styluses needs to be charged before using for the first time.

To charge Stylus use the Mini USB cable and connect the stylus to PC





Registered Offices

Hannover: Georgstraße 38, 30159, Hannover, Germany, Ph: +49 (0)511 93621 188

Delhi NCR: Plot no. C-98, Sector- 65, NOIDA, 201301, Ph: +91 (0)120 435 9466

Bangalore: 1140, Sector 7, HSR Layout, 560102, India, Ph: +91 (0)888 474 3388

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located for operating in conjunction with any other antenna or transmitter.