
## **User manaul**

- 1 need to be used with the host, the first use needs to pair, press 2H and 4H double key pair code at the same time.
- 2. the remote control with code indicator light, light up when pressing the button, after the code is successful, the remote control press the button to receive the buzzer will respond.
- 3. The remote control button is as follows:

		key assignme nts
FAN ON/OFF	Short press to turn on the fan, short press again to turn off the fan	0x11
1 (-)	Wind a	0x12
2 (MID)	Wind speed second gear	0x13
3 (+)	Wind speed three gears	0x14
LIGHT ON/OFF	Short press release to turn on the light, short press again to turn off the light	0x0B
	Long press detected	0x0E
	Continue to long	0x0C
	Long press let go	0x0D
F/R	Switch the fan is working in positive or negative mode	OXOF
2Н	Turn off lights and fans after 2 hours countdown	0x08
4H	4 hours to turn off lights and fans	0x09

## combination key

2H+4H Press at the same time  Boot to code  0x05
--



## **FCC Statement**

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital de vice, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protec tion against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help important announcement

## **Radiation Exposure Statement**

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.