



ainenne

Quick Start Guide

(User's manual)

Warranty included

Model : AIN-US

Thank you for purchasing this product. Please be sure to read "For safe use" first.

In order to use this product properly, please follow the instructions in this manual to complete the setup. For details, be sure to refer to the web instruction manual on the official website.

For details on how to use it

The web instruction manual on the official website provides more detailed instructions on how to use ainenne. Please be sure to read it and use it correctly.

URL : <https://ainenne.com/manual/>

Trademarks

SD is a trademark of SD-3C, LLC. WPS (Wi-Fi Protected Setup) is a registered trademark of Wi-Fi Alliance. AOSS is a registered trademark of Buffalo Inc. AOSS is a registered trademark of Buffalo Corp. Company names, logos, product names, and software names mentioned in this document are trademarks or registered trademarks of their respective companies. First Ascent Corporation uses these marks under license. All other trademarks and tradenames are the property of their respective owners.

The copyright of this document is held by First Ascent, Inc. No part of this manual may be reproduced or duplicated in any form or by any means without the prior written permission of First Ascent, Inc. We have made every effort to ensure that the contents of this manual are correct, but if you have any questions, please contact your dealer. When exporting or supplying this product (including accessories), please confirm the rules and regulations of the Foreign Exchange and Foreign Trade Law and the laws related to foreign export control, and take the necessary procedures.

Checking the contents


Before using the product, please make sure that you have all the following items.

If there are any missing or damaged items, please contact your dealer.
ainenne main unit / AC adapter / Quick Start Guide (this book)




Names of parts

Front



Control panel


Bottom



■ Control panel

Sleep recording button

Record the date and time when you start tucking them in, when they go to sleep, and when they wake up.



Settings

In order to connect this product to the Internet and use various functions, it is necessary to connect this product to a wireless LAN.

■ Installation

1 Connect to a power source

- Connect the DC plug of the AC adapter to the DC input terminal (on the bottom) of the product and connect the AC adapter to the power outlet.
- The operation lamp will light up when the power is turned on, and the operation lamp will turn off after startup is complete.
- This product starts up automatically when it is connected to a power source. There is no power switch.

■ Connecting to a wireless LAN

1 Connecting using the wireless LAN Easy Connection

【 Connecting using the wireless LAN Easy Connection 】

- When connecting to a wireless router using the Wireless LAN Easy Connection, please do so as close to the wireless router as possible.

1 Press the Settings () button, and select "Wireless LAN Settings" > "Wireless LAN Easy Connection".

2 Within 60 seconds, press the WPS button on the wireless LAN router.

You may also see "AOSS", "Easy Wireless Start", or "Wireless Settings

Button".

When you see the message "You have successfully connected using the wireless LAN Easy Connection," the connection is complete.

【 Connecting by specifying the SSID 】

1 Press the setting button (), and select ", Wireless LAN Settings" > "Specify SSID".

2 Use the buttons to select the SSID you want to connect to, and then press the Enter button.

This product should be connected in the 2.4GHz frequency band.

3 Enter the password and press the Enter button.

- Set the password by using  buttons while watching the screen. If you are using a computer that has an encryption key, you will need to use the "encryption key", "security key", "network key", or even "WEP key" or "WPA key" depending on the encryption standard.

When the message "Successfully connected" is displayed, the connection is complete.

■ Initialization

【 Setting the alarm 】

- When you set an alarm, the light will gradually brighten according to the time you set.
- You can set the alarm to sound at the time when the brightness is at its maximum.
- Press the light on button () to stop the alarm sound.

1 Press the Settings (⚙️) button to select "Alarm Settings".

2 Follow the instructions on the display to set the alarm.

【Setting the language】

1 Select "Language Settings" > "Select Language"

2 Follow the prompts to set the language.

【Connecting to the app】

1 Select "App Linkage" to display the linkage code.

2 Launch the app and enter the linkage code displayed on the screen according to the app's instructions.

- When linked to an app, you can check your sleep record from the app.

Download the app here. ➔



Download

In such a case

- If it does not work, check the following items.

Condition	Reasons	Procedure
It won't turn on.	<p>The AC adapter is not securely plugged into the outlet.</p> <p>The DC plug of the AC adapter is not securely plugged into the DC input terminal.</p>	<p>Plug the AC adapter into the wall socket securely.</p> <p>Make sure to insert the DC plug of the AC adapter into the DC input terminal.</p>
The wireless LAN is not connected.	Trying to connect at 5GHz.	The wireless LAN of this product is for 2.4GHz only. Use a wireless LAN router that can use 2.4GHz.
Can't connect to the Internet.	The wireless LAN router is not connected to the Internet.	Connect other devices such as a smartphone to the same wireless router and check if you can connect to the Internet via wireless LAN.
Display does not show up.	The display will turn off after a certain period of inactivity.	Press the ENTER button or any other button to turn on the display.

- If the above steps do not solve the problem, unplug the AC adapter and restart the product. If this does not solve the problem, please contact your dealer as there is a possibility of malfunction.

Safety Precautions

First, please read this "Safety Precautions" carefully to ensure proper use. This section explains what must be observed in order to prevent harm to people and damage to property.

Meaning of graphic symbols



This symbol calls for attention.



This symbol indicates prohibition.



This symbol indicates that it must be done.



Warning

Indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury.



- Do not use anything other than 100V AC.
- Do not use overseas.

This may cause a fire or electric shock.

This unit is for use in Japan only. Do not use this unit with a ship's power supply, a generator, or an overseas power supply with a different voltage.

- Do not use the product in a manner that exceeds the rating of the outlet or extension cord.
- When unplugging the AC adapter from the power outlet, do not pull the cord forcibly.

Do not pull on the cord. Pulling on the cord may cause damage to the cord, resulting in fire or electric shock.

If the AC adaptor is damaged, contact your dealer.

- Do not allow infants to lick the AC adapter.

It may cause injury or electric shock.

- Do not connect the supplied AC adapter to any other equipment.
- Do not connect the supplied AC adapter to any other device.

Doing so may result in fire or electric shock.

Do not connect any other AC adapter than the one supplied with this product to this unit.

- Do not damage the AC adapter.
- Do not pull on the AC adapter cord.

Do not scratch, modify, forcibly bend, pull, twist, place heavy objects on, or pinch the cord. Doing so may damage the power cord, resulting in fire or electric shock.

- Do not put the packing bag or small parts within reach of infants.

Covering the bag or accidentally swallowing small parts can cause choking.



Do not plug or unplug the AC adapter or DC plug with wet hands, as this may cause electric shock, burns, or injury.



- Remove dust from the plug of the AC adapter periodically.
Dust and moisture can cause poor insulation, which may result in fire or electric shock.
- Make sure the AC adapter is plugged in all the way to the back of the outlet.
Be sure to plug the AC adapter all the way into the wall socket to prevent fire or electric shock due to short circuit.



- In the event of an abnormality or malfunction, stop using the product immediately, unplug the AC adapter from the power outlet, and disconnect the DC plug from the main unit.
There is a risk of smoke, fire, and electric shock.
(Examples of Abnormalities)
 - Unusual sounds, smells, or smoke.
 - Water or foreign matter got inside.
 - The unit has been dropped or a part of the unit has been damaged.
 - The AC adapter cord is damaged.

→ Discontinue use and contact your dealer.
- When cleaning or moving the unit, be sure to unplug the AC adapter from the outlet and disconnect the DC plug from the unit.
Failure to do so may result in electric shock or injury.



- If lightning starts to strike, do not touch the unit, the AC adapter itself, or the AC adapter cord.

This may cause electric shock.



Caution

Indicates a potentially hazardous situation that, if not avoided, could result in personal injury or property damage.



- Do not install in an unstable place.
- Do not place the product in a location where it could fall on an infant.
Placing the product on a wobbly or tilted stand may cause it to fall, resulting in injury or damage to household goods. Install the product on a level and stable surface.
- Do not use near any heat sources.
Failure to do so may result in fire, electric shock, or burns.



- Do not disassemble, repair, or modify the product.
Failure to do so may result in fire, electric shock, injury, or malfunction.
For repair, please contact your dealer.



- Do not spray water.
- Do not use the product in a place where it may be exposed to water.
This may cause a fire or electric shock.



When not using the product for a long period of time, unplug the AC adapter from the power outlet and disconnect the DC plug from the main unit. When not using the product for a long period of time, unplug the AC adapter from the power outlet and disconnect the DC plug from the main unit.



- The power cord should not be caught or wrapped around the unit, as this may cause an accident. Do not allow infants to touch the power cord.

Use of wireless functions

Frequency band used	2.4GHz
Modulation method	DS-SS method/OFDM method (IEEE 802.11b/g/n)
Assumed interference distance	40m or less
Availability of frequency change	Use all bands and avoid the "premises radio station" and "specified low power radio station" bands

■ Precautions for radio waves

- This product uses a wireless LAN. The wireless LAN used is certified as a radio equipment for low-power data communication system radio station based on the Radio Law, and does not require a radio station license.
- Since this wireless LAN has obtained construction design certification, disassembly or modification of this product may be punishable by law.
- This wireless LAN uses radio waves in the 2.4GHz band. Therefore, do not use it in places where radio interference may occur, such as microwave ovens, or near objects that use 2.4GHz radio waves.
- The radio channel of this wireless LAN uses the same frequency band as the following devices and radio stations.

Industry-Science-Medical equipment

2.4GHz band mobile identification radio equipment for premises radio stations (radio stations requiring a license)

Specified low-power radio stations (radio stations not requiring a license)

This wireless LAN may interfere with the above devices and wireless stations, so please be aware of the following points.

- (1) Before using this wireless LAN, make sure that there are no 2.4 GHz band mobile wireless devices operating in the surrounding area.
- (2) In the unlikely event that radio interference occurs from this wireless LAN to 2.4 GHz band mobile wireless equipment, immediately change the frequency channel to be used to prevent radio interference.

Warranty

This document is a promise to perform repairs according to the contents of the warranty terms. If a malfunction occurs during the following period from the date of purchase, please fill in the customer column and contact us.

Please be sure to request repair with this warranty card.

The warranty card will not be reissued, so please keep it in a safe place.

First Ascent, Inc.

Sagami Bldg. 2F, 7-13-6 Ginza, Chuo-ku, Tokyo 104-0061,

Japan

For inquiries, please contact : info@first-ascent.jp

Name		Product name	ainenne Model : AIN-US
Address		Warranty period	One year from date of purchase
Phone number		Date of purchase	Please attach a document (receipt, etc.) that confirms the date of purchase.

Warranty Policy

Repair warranty

This product will be repaired or replaced free of charge only in the event of a malfunction of this product that occurs under proper operating conditions within the warranty period stated in the warranty card.

Free Warranty

The warranty does not apply in the following cases

- (1) If the dealer does not indicate the date of purchase on the warranty card, or if the dealer cannot provide proof of the date of purchase (such as a receipt).
- (2) If the warranty card is not presented, the product will be disposed of.
- (3) If the warranty card is found to be forged or altered.
- (4) If the product is damaged due to modification, disassembly or repair by the customer.
- (5) In the event that the product malfunctions due to non-compliance with the usage environment and methods specified by our company.
- (6) In the event of failure or damage due to shock, dropping, etc. occurring during transportation after the purchase of the product.
- (7) In case of failure or damage due to external factors such as earthquake, fire, other natural disasters, pollution, etc.
- (8) In the event that any other reason that does not warrant free repair or replacement is discovered.
- (9) When any of the following prohibited operations are recognized in the built-in SD card. Permanent recording and logging applications Permanent playback applications

Repair

- For repair, take the product to your dealer or distributor with this warranty card attached to the product.
- If it is difficult to repair the product and we are unable to replace it with the same model, we may replace it with another product that has the same or better performance than the product covered by the warranty.
- Regardless of whether there is a charge or no charge, we will dispose of any old parts or products that have been replaced as a result of repair.

Disclaimer

Except in the case of intentional or gross negligence on the part of our company, our liability for damages for default or tort shall be limited to the purchase price of the product.

We shall not be liable for any consequential, indirect, or psychological damages or lost profits resulting from the failure of this product.

Scope of Validity

This warranty is valid only in Japan.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device should be installed and operated with minimum 20 cm between the radiator and your body.