

510152 User Manual

How to working:

1. To turn on the device, press the top button  1.5-2 seconds, the light will flash.
2. Press top button 1 second to change the vibrator pattern and speed. The light will flash as the pattern/speed is changed
3. To heat the device, press the bottom button  for 1 second. The button will light up. Please note the heating function can only be used when the top/power button (vibration button) is on.
 - The device takes 3 minutes to heat up.
 - Press heat button once to reach temperature of 100.4°F / 38°C
 - Press heat button twice to reach temperature of 113°F / 45°C.
 - CAUTION: For your safety, the heat will automatically turn off once it has reached top temperature of 113°F / 45°C
 - Do not press the heat button more than twice.
 - The vibration & heating functions can be used separately so you can get the device warmed up before using the vibration function. (Top/power button needs to be powered on first)
4. To turn off, press and hold the top button for 3 seconds.



How to charge it:

1. Before charging, make sure the outlet is free from water or lubricant residue.
2. To charge the device, attach the magnetic cord to the back/bottom of the device and plug the USB cord into a power source.
3. Unplug the device before use.
4. 3 hours of charging time will provide up to 90 minutes of pleasure. Power button blinks when charging, and stops blinking / stays illuminated when fully charged.



FCC Warning:

1. This device should be installed and operated with minimum distance 0cm between the radiator&your body.
2. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference, and
 - (2) This device must accept any interference received, including interference that may cause undesired operation.
3. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
4. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause

harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.