




Remote Control Car User Manual




<PACKAGE CONTENTS>



<RC CAR'S DETAILS>



<REMOTE CONTROL FUNCTIONS>




-1-

<BATTERY INSTALLATION>

1.Rc Car's Details


1. Plug the USB cable into a 5V power source (e.g. PC, phone charger, power bank) with maximum 2A output.
2. Plug the charging cable into the port in the back of the vehicle.



Warm Notice:

1. Do not charge the battery immediately after use, let's the battery cool for at least 10 minutes.
2. The charging indicator will light up during charging and light will turn off when finishing charging.

2.Remote Control Battery



1. Open the battery cover.
2. Install 2x1.5V AAA batteries(not included) in the correct positive (+) and negative (-) polarities direction.
3. Close the battery cover.

Warm Notice: If the remote control will not be used for a long time, please make sure to take out the batteries.


-2-

<OPERATION>


1. Pairing

Once batteries are inserted into the car and remote, turn on the car and the remote, both will automatically pair.


2. Forward / Backward



3. Left rotation / Right rotation



4. Left-hand dumper / Right-hand dumper



5.Auto Demo Mode

Press the auto demo button, and the car will enter auto show mode, press other button to exit.

-3-

<SPECIFICATIONS>

Materials: ABS

Drive system: 2WD

Frequency: 2.4GHz

Dimension: 120x139x124mm

Car Weight: 246.3g

Control Distance: about 30 meters

Battery type for car: 3.7V Li-ion battery(included)

Battery type for remote control: 1.5V AAA batteries(not included)

<NOTE>

1. Please play the car on clean flat surfaces.
2. Adult supervision recommended at all times.
3. Remove all batteries when not using it for a long period of time.

<TROUBLE SHOOTING>

PROBLEM	SOLUTION
The wheels cannot move	1. Power switch is off, please turn on. 2. Battery exhausted, please charge. 3. Re-frequency.
Suddenly stopped during operation	1. Check if the battery is electrical. 2. Replace or recharge the battery.
Remote control power indicator lashes	Replace the battery.
R/C car becomes slow	Replace or recharge the battery.

-4-

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.