





## User Manual



### Wireless Washable Mouse

\* Please read this user manual carefully before you start using this product.

#### Interface introduction



#### Specifications

Working Methods:	Optical mouse
Dimensions:	115 x 62 x 36 mm
Net weight:	90Gs
DPI Maximum:	110Gs
Connection:	RF 2.4GHz
Working distance:	Abt 10m
Input voltage:	1.5V
Power:	1pcs x AA
Splash, water, and dust resistant :	Rated IP68(max)
Key Life:	5 million Keystroke
Operating temperature:	0°C to +45°C
Storage temperature:	-10°C to +60°C

#### Antimicrobial

Mouse with antimicrobial protection is formulated to suppress the growth of odour and stain-causing microorganisms, and is not intended for use as a replacement to proper hygiene or for prevention of infectious illness.

#### Europe – EU Declaration of Conformity

The product is conformity with all the essential requirements and other provisions of the European Council Directive: Directive 2014/53/EU on Radio Equipment and RoHS Directive 2011/65/EU.

#### Disposal of waste equipment by user in private household in the European Union

This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

#### FCC ID

FCC Caution: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference;
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment causes harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID: 2A32M-ECT409W



#### General Cleaning Instructions

##### Spray-Wipe-Spray Method

- Check whether the battery sealing screw cap is tightened to prevent liquid immersion and damage to the product during cleaning.
- To avoid accidental keystrokes, entering or deleting important data, unplug the USB adapter from the device, before cleaning.
- Clean the surface of the item by wiping, gently brushing, dipping it or by following the "spray-wipe-spray" protocol outlined as follows. Spray the product with disinfecting spray, wipe away dirt and organic solids with a cloth then spray the product completely again with disinfecting spray, allowing the disinfectant to remain on the product for at least five seconds.
- Either wipe with dry cloth or shake gently and allow to air dry.

##### Sanitising Dip Method

- Check whether the battery sealing screw cap is tightened to prevent liquid immersion and damage to the product during cleaning.
- To avoid accidental keystrokes, entering or deleting important data, unplug the USB adapter from the device, before cleaning.
- Soak and flush the mouse with approved cleaning agents and disinfectants.
  - Water temperature should be less than 50° C (120° F) and water should not be deeper than 50 cm.
  - Don't use abrasives.
  - Recommended cleaning materials: dish washing liquid, non-abrasive cleanser, general purpose cleaner, disinfectant, soap water, rubbing alcohol / surgical spirit.
- Rinse thoroughly to remove any residual cleaning agent.
- Drying the mouse.
  - Shake the mouse to remove any residual water.
  - Dry off with a clean towel.
  - Do not use a hot-air drier.
  - To extend mouse life: Recommended to air dry overnight (about 8 hours).
  - Reconnect the mouse.

**WARNING:** The USB adapter is not washable