


Wireless Controller Instruction Manual



- 1. SHARE/BACK(PC MODE)
- 2. TOUCHPAD
- 3. HOME BUTTON
- 4. OPTIONS/START (PC MODE)
- 5. ACTION BUTTONS
- 6. R3/RS (PC MODE)
- 7. TURBO BUTTONS
- 8. D-PAD
- 9. L3/LS (PC MODE)

Operation Guides

A.PS4 Mode

Plug the USB cable into the USB port of the PS4 console. For the first time, press the HOME button once according to the instructions and it begins to serve.

B.Bluetooth Mode (include Apple iPhone iPad device and Android smart phones)

STEP 1: Turn on the controller pairing mode

Before you can connect your wireless controller via Bluetooth, you need to activate pairing mode:

Press and hold the Home Button and SHARE button on the wireless controller at the same time. The light bar on the back of the wireless controller will start flash as long as the pairing mode is active.

STEP 2: Connect wireless controller via Bluetooth

On your Apple device, go to the Bluetooth settings and turn Bluetooth ON. Select scan for new devices and then choose "DUAL SHOCK 4 Wireless Controller"

You can now use your wireless controller to control compatible games and applications on your device.

Support iPhone, iPad and Apple TV.

- 10. R1/RB (PC MODE)
- 11. LED LIGHT
- 12. L1/LB (PC MODE)
- 13. L2/LT (PC MODE)
- 14. AUDIO PORT
- 15. MIC SWITCH
- 16. PROGRAMMABLE BUTTONS
- 17. R2/RT (PC MODE)



Functions

1.Turbo Function: press and hold a Motion button to activate the skill continuously (After the successful setting, the LED light will flash when you press the Motion button)

a.Setting Steps: Long press "TURBO" button and any motion button for 2 seconds simultaneously, then release "TURBO" button to complete the setting.

b.Cancel the Settings: Repeat the above steps to cancel the turbo function.

2.Mapping function settings

Step 1: Press and hold the Turbo button for 3 seconds, the LED light turns green;

Step 2: Press any M1/M2 button, the LED light flashes green;

Step 3: Press the M1/M2 mapping button once, the LED flashes white;

Step 4: Press the M1/M2 button, the LED color returns to the current mode after the setting is successful.

For example, if you want to set the M1 button as the A function, firstly press and hold the Turbo button for 3 seconds, then press the M1 button, the LED light will flash;

Then press the A button once before press the M1 button again, the setting is successful. Press the M1 button to displace the A button function, the original A button's function remains unchanged.

Federal Communications Commission Notice

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must acceptany interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.