




## NEVLERS Karaoke Microphone Instructions

### I .Buttons Operation




1. “” Hold:To turn ON/OFF Press:To switch modes

Switch mode 1: connect to Shutter,use to take photo.

Switch mode 2:Radio Mode

Switch mode 3:Auxiliary Mode

Switch mode 4: Bluetooth mode

2. “” Press :For the previous song
3. “” Press: For the next song
4. “” Press to Play/Pause music.

Under the FM radio mode hold to automatically scan,

Or click up or down to manually change stations.

Android:Connect via Bluetooth.

Open the selfie camera on your phone.

Press it to take a selfie.

iOS:Press the power button into “shutter” mode.

Connect to “shutter” in Bluetooth.

Open the selfie camera on your phone.

Press it to take a selfie.


5. 

While music is playing,press to automatically lower the lyrics and

Mostly hear just the tune,and press again to turn the lyrics back on.

After inserting a TF/SD card:Hold to play music from the card.

6. “+” Increase volume
7. “-” Decrease volume
8. Remix:Turn on /off Echo






## NEVLERS Karaoke Microphone Instructions

### II.Charging your Karaoke Microphone

1. Use the wire that has a micro USB on one end and USB on the other.
2. Plug the micro USB into the AUX slot under the microphone and plug the USB into a Computer or power adapter that plugs into a wall outlet.
3. A red light will turn on near the AUX slot,which indicates that the microphone is charging. Once the microphone is fully charged,the red light will turn off.
4. The microphone should be charged for approximately 4-5 hours which should give you about 6-8 hours of usage time.

### III.Wireless Karaoke

1. Hold the  button to turn it on and off.Click it to switch modes when the device is on.
2. Wireless connection:Enable Bluetooth on your device, connect to Nevlers.
3. Adjust the volume and reverberation/echo.
4. Enjoy your karaoke.

### IV.Recording with your mobile phone

1. Connect the recording wire:Insert the Micro USB wire into the AUX slot under the mic,and The 3.5mm end into the earphone jack of your phone.
2. Open the karaoke software on your phone, such as:USING,Kugou Music or other recording APP's,select your favorite song and record the song with one of the above mentioned methods
3. Test and save the song using the instructions of the karaoke software.

### Technical Parameters

- Output Power:5W • Frequency Range:100HZ~10KHZ
- Max Sound Pressure Level:>115DB 1KHZ TDH<1%
- Reverberation Mode:sound effect reverberation
- Power Supply:Built-in 18650 Li-battery
- Battery Capacity:1200mAh • Charging Power:DC5V

## **FCC Statement**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference.

(2)This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note:This equipment has been tested and found to comply with the limits for a class B digital device,pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and,if not installed and used in accordance with the instructions,may cause harmful interference to

radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.