


Lorawan gateway instructions

1 . Appearance introduction



- Gateway ID card: Including SN code, MAC address and QR code
- Power indicator



- Power
- Nameplate

- Wan
- Bluetooth reset
- Antenna interface



Tear invalid: if the label is broken, the equipment will no longer be warranted

2 . Operation process

Connect the device to the antenna, connect the power supply through the adapter, wait for 5 minutes, and the power indicator will become constant green. Press the Bluetooth reset button on the back once to identify Bluetooth pairing in the app; When the equipment works normally, it is recommended to maintain normal temperature and humidity.

3 . Precautions for full operation and maintenance

The normal temperature of the equipment is 0-60 °C. It is recommended to keep ventilation in high temperature environment; In order to dissipate heat, the equipment does not have waterproof capacity to avoid falling into the water, and the equipment does not enjoy warranty service when it enters the water; Avoid falling from height.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

The equipment complies with FCC Radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

.