

## Parameters

Model	A6 Pro
Net weight	Approx 16.15 KG
Expanded size	1127x440x1190mm
Applicable age	Age 14+
Applicable height	130~200 CM
Maximum load	100 KG (254 LB)
Maximum speed	25 KM/H (15.5MPH)
Mileage	Max 30 Kilometers (18.64Miles)
Gradeability	About 15%
Protection grade	IPX5
Charging time	About 6H
Battery capacity	7800mAh
Voltage	36V
Motor	350W
BMS management	Over-charge, Over-temperature, Over-discharge, Over-current, Short circuit, Over-voltage
Brake system	Durm brake + Electronic brake
Connection method	Bluetooth
Tire size	10 inch puncture-proof tubeless tyres


## Assembly

1. Pull the folding handle upwards until there is a click sound, and pull the folding handle to confirm whether it is locked.
2. Manually connect the fixing seat and the data cable in the front tube, and check whether it is turned on normally.
3. Insert the fixing seat into the front tube, and use a T-shape Allen Key to tighten the six screws.



## Charge Your Scooter

1. The indicator light of the charger turns green when connected the charger to the power supply.
2. Inserting the charging plug, and the indicator light will turns from green to red.
3. After charging, the indicator light turns from red to green.



### *Attention:*

1. Only use the original power adapter when charging.
2. Keep away from children and animals when charging, and keep away from flammable materials.
3. Do not charge or use the battery if it emits a peculiar smell, overheats or leaks.
4. Do not open the battery pack or insert anything into the charging port as the battery contains dangerous substances.
5. If it won't be used for a long time, please fully charge it first, store in a cool and dry place, and fully charge it every 30 days.

# 1 Safety Notes

## 1.1 About safety

• There's risk for any vehicle, including e-scooter. For your safety, please learn to ride safely and obey the local rules and enjoy the riding.

• Please check if the tire is damaged or the spare parts are tight before riding. Please contact local distributor for any unexpected situation.


• Please do not do anything that may harm other people or their properties with e-scooter.

• Any conversion of the e-scooter is prohibited as it will change its performance or damage the structure, which may bring serious injury.

• Please do not put the electric scooter in the water, which will not only damage the electric scooter, but also cause a safety accident.

## 1.2 Safety Precautions


Please note that you may lose balance, crash or fall down when you ride an e-scooter. To avoid injury, you should be familiar with this manual and keep the e-scooter in good condition.



⚠ Safety measurements should be taken before riding, eg: wear sportswear, helmet, kneecap, elbow pads and so on.



⚠ DO NOT ride when it rains.



⚠ DO NOT ride with loading  
DO NOT ride with two people or more, only for one rider.



⚠ People between 14 and 60 years old may use the product, pregnant is not allowed to ride the e-scooter.




⚠ Max Loading: 100 kg



⚠ DO NOT ride after drinking or taking medicine.



⚠ DO NOT make phone call or listen to music when you ride the e-scooter.



⚠ Be careful of the road with roadblock, sandstone, ponding, mud, wet, ice and snow, slope (angle >15°) stairs, dark area when you are riding.