

LITTLE TIDDI

Smart Children's Sleep Trainer, Sound Machine,
Alarm Clock, Nap Timer and Night Light

SETUP GUIDE



Children's alarm clock

Model: NZ03 FCC ID: 2A4FO-NZ03

One-Year Limited Warranty

After-sales mailbox: LittleTiddi@pkqshop.com
Customer Service Number: [469-353-4385 \(PST 8:00-16:00\)](tel:469-353-4385)

CATALOGUE GUIDELINES



Device settings :

1-16 Page



APP Settings :

17-31 Page

Customer Service Number: 469-353-4385 (PST 8:00-16:00)

MEET LITTLE TIDDI





Fig. 1 LITTLE TIDDI




Customer Service Number: 469-353-4385 (PST 8:00-16:00)


IN THE BOX



LITTLE TIDDI



ADAPTER



CR2032 BATTERY
(Pre-Installed)

WARNING:

- Not suitable for children under 36 months
- Choking hazard - small parts
- Parental supervision required

SETUP AND MAINTENANCE

SET UP

Attach the adapter jack to the LITTLE TIDDI's base and plug into a 100V-240V household outlet (Fig. 2).




Fig. 2 Adapter

INSTALL BATTERY

LITTLE TIDDI comes with a pre-installed CR2032 battery. Pull the clear tab to remove the insulation sticker. Removing the insulation sticker will allow LITTLE TIDDI's memory settings to be saved.

STORE

LITTLE TIDDI should be left on display, or stored in its box or a cool, dry place.

CLEAN

Wipe off dust with a soft, damp cloth. Do not use liquids or abrasive cleaners.

USER TIP

LITTLE TIDDI needs to work with plugged in. When LITTLE TIDDI is not plugged into an outlet, the included CR2032 battery preserves basic memory functions.

Customer Service Number: 469-353-4385 (PST 8:00-16:00)

DISPLAY

 ALARM	 SOUND+LIGHT	 SOUND
 LIGHT	 LOCK	 COUNTDOWN

CONTROL PANEL

To program all settings, use the control panel on the bottom of LITTLE TIDDI (Fig. 3).




Fig. 3 Control Panel

TIME

When LITTLE TIDDI is first plugged in, the display will read “12:00 AM”.

STEPS:



1. Press SET

The word “SETTING” will appear on the display.

2. Press TIME

The time will flash. Use (+/-) to adjust (Hold for rapid adjustment).

NOTE: Press TIME again and use (+/-) to toggle between 12/24H mode (**AM/PM** will appear under 12H mode).

3. Press SET

To exit Time mode.

4. Press TIME

To loop back to the beginning.

USER TIP

Single press to lock and prevent accidental change of settings. Press and hold for 2 seconds to unlock the control panel.

ALARM

STEPS:



1. Press SET

The word “SETTING” will appear on the display.

2. Press ALARM

The word “ALARM” will appear and alarm time will flash.
Use (+/-) to adjust the alarm time (Hold for fast adjustment).

3. Press ALARM

The alarm icon will appear. Use (+/-) to adjust the alarm volume (level 1 to 5).

4. Press SET

To exit Alarm mode.

5. Press ALARM

To loop back to the beginning.

Single press **ALARM** to toggle the alarm on or off. From off to on, the set alarm time will flash for 2 seconds, and alarm icon will stay on display. The alarm sound is set and can NOT be changed.

ALARM

When the alarm sounds, the alarm facial expression will display. Alarm will last 8 minutes and stop, if not interrupted by any action of the user (Fig. 4).



Fig. 4 Alarm Goes Off

SNOOZE

Tap **SNOOZE** once to mute the alarm for 9 minutes. After 9 minutes, alarm will sound again and you can repeat the process multiple times (Fig. 5).



Fig. 5 Snooze Active

TURN OFF

To cancel the snooze at any time or turn off the alarm while it is sounding, press and hold **SNOOZE** for 2 seconds or press any button except (+/-) on the bottom.

GOOD HABITS WITH LITTLE TIDDI

When it is time to sleep, LITTLE TIDDI will close its eyes so your child will go to bed. When it is time to wake, LITTLE TIDDI will greet your child with a smile and the light ring will turn **GREEN** – green means go!

LITTLE TIDDI also teaches your child to wait for good things to come. You have the option to turn on the “**PLAY**” setting, during which period (10, 20 30...90 min before the wake time you set) LITTLE TIDDI will glow **PALE GREEN**, so that your child will wake/play quietly in his or her room until the light turns **GREEN** – again, green means go!

NOTE: You can also turn off **PLAY** setting.

EXAMPLE (Fig.6)

LITTLE TIDDI's wake time is set to 7:00AM and play period is 10mins, the light ring will glow pale green at 6:50AM and turn green at 7:00AM.



Fig. 6 Sleep Trainer Example

SLEEP TRAINER - SLEEP MODE

STEPS:

1. Press SET

The word "SETTING" will appear on the display.

2. Press SLEEP

LITTLE TIDDI will show a sleeping expression and time will flash on display. Use (+|-) to adjust the sleep time (Press and hold for rapid adjustment).

3. Press SLEEP

Use (+|-) to turn on sound and light mode, sound only mode, light only mode, or sleeping expression only mode (Fig. 7).




Fig. 7 Four Sleep Mode

4. Press SET

To exit the Sleep mode.

5. Press SLEEP

To loop back to the beginning.

SLEEP TRAINER - SLEEP MODE

To toggle the sleep mode on or off, press **SLEEP**. From off to on, time and sleep icon will blink for 2 seconds, then the sleep icon will stay on the display.

USER TIP

The sleep sound is set in **SLEEP SOUND OPTIONS** (Page 12), and the sleep light is set in **NIGHT LIGHT OPTIONS** (Page 13).

WHEN THE SLEEP MODE IS ACTIVATED:

1. Press **LIGHT** repeatedly to adjust the light countdown time ranging from 90 minutes to 15 minutes or Stay Lit (ALL) or OFF.
2. Press **SNOOZE** repeatedly to adjust the light brightness (level 1 to 4).
3. Press **SOUND** repeatedly to adjust the ringtone countdown time ranging from 90 minutes to 15 minutes or Keep Sounding (ALL) or OFF.
4. Use **(+|-)** to adjust the ringtone volume (level 1 to 5).

SLEEP TRAINER - WAKE MODE

STEPS:



1. Press SET

The word "SETTING" will appear on the display.

2. Press WAKE

The word "WAKE" will appear and wake time will flash on display. LITTLE TIDDI will show a smiling expression and the light will glow green. Use (+/-) to adjust the wake time (Press and hold for rapid adjustment). The "WAKE" will automatically turn off after 2H if not interrupted by any action of the user.

3. Press WAKE

Press WAKE again to enter the Play Setting. LITTLE TIDDI will show a playful expression and the light will glow pale green. Use (+/-) to adjust play time ranging from 90 minutes to 10 minutes or OFF.

4. Press SET

To exit the Wake mode.

5. Press WAKE

To loop back to the beginning.

From off to on, the wake icon and set wake time will blink for 2 seconds, and the wake icon will stay on the display.

USER TIP

You can press SNOOZE 2s to turn off the green/pale green light when the wake/play mode is activated.

SLEEP SOUND MACHINE

SLEEP SOUND OPTIONS

1. Press SET

The word "SETTING" will appear on the display.

2. Press SOUND

The word "SOUND" will appear below the line and first sound option S 01 will flash. Use (+/-) to choose among the follow 4 options: S 01 music box, S 02 lullaby, S 03 ocean wave, S 04 white noise.

3. Press SET

To exit Sleep Sound setting.

SOUND TIMER

Press SOUND repeatedly to adjust the duration of sounds. Options available are ALL (continuous), OFF, 15/30/60/90 minutes. The setting will automatically be saved after 2 seconds and exit.

Use (+|-) to adjust the sound volume while it is sounding (level 1 to 5).

USER TIP

When an alarm is sounding, it will override the sound machine.

NIGHT LIGHT

NIGHT LIGHT OPTIONS

1. Press SET

The word "SETTING" will appear on the display.

2. Press LIGHT

The word "LIGHT" will appear and "L 01" will flash on display. The night light will glow red color. Use (+|-) to choose the light color (L01 is red color; L02 is blue; L03 is purple; L04 is yellow; L05 is loop color).

3. Press SET

To exit Night Light Option mode.

LIGHT TIMER

Press LIGHT repeatedly to adjust the duration of night light. Options available are ALL (continuous), OFF, 15/30/60/90 minutes. The setting will automatically be saved after 2 seconds and exit.

Press SNOOZE repeatedly to adjust the night light brightness when it lights up (level 1 to 4).

USER TIP

For optimal sleep quality, we recommend using the red night light at bed time!

NAP TIMER

NAP OPTIONS

1. Press SET

The word "SETTING" will appear on the display.

2. Press NAP

Use (+/-) to turn on sound and light mode, sound only mode, or light only mode (Fig. 8). **NOTE:** The nap sound is alarm sound and the light color is green - both are set and can NOT be changed.

3. Press SET

To exit Nap setting.




Fig. 8 Three Nap Mode

NAP TIMER

Press NAP repeatedly to adjust the duration of nap timer. Options available are OFF, 15/30/60/90/180 minutes. The setting will automatically be saved after 2 seconds and exit.

NOTE: When the nap is finished, LITTLE TIDDI will wake up and the alarm sound will play (if you choose sound mode) and/or green light will glow (if you choose light mode). To turn off the nap timer alarm or light, press and hold SNOOZE for 2 seconds or press NAP if it's in unlocked mode.

BRIGHTNESS CONTROL

1. There are 5 brightness levels for LCD Display and Facial Expression. To adjust the brightness, press **TIME** repeatedly to scroll through the options.
2. There are 4 brightness levels for light ring. When it lights up, press **SNOOZE** repeatedly to scroll through the options.

REPLACE BATTERY

Using the included small torx screwdriver, remove the screw from the battery cartridge (Fig. 9). Insert the battery positive side up and fully slide the cartridge back into the compartment. Put screw into place to secure battery compartment.




Fig. 9 Battery Compartment

LOCK MODE

Single press  to lock and prevent accidental change of settings. The following features still function in lock mode.

- Press **SNOOZE** once to snooze for 9 minutes.
- Press and hold **SNOOZE** for 2 seconds, or press any button except **(+/-)** on the bottom to turn off the alarm sound when the alarm is sounding.
- Press and hold **SNOOZE** for 2 seconds to turn off the nap timer alarm or light when the nap timer is finished.
- Press **SNOOZE** repeatedly to adjust the night light brightness when it lights up (level 1 to 4).
- Press **SNOOZE** for 2 seconds to turn off the pale green/green light when the play/wake mode is activated.
- Press **TIME** repeatedly to adjust the brightness of LCD display and facial expression (level 1 to 5).

DOWNLOAD REGISTER & LOG IN SMART LIFE APP

1. Download the Smart Life APP into your mobile device from App Store/Google Play or by scanning QR code (Fig. 10).
2. Create an Account and Log in (Fig. 11)(Fig. 12).

Download "Smart Life"



Android/IOS

Fig. 10




Fig. 11



Fig. 12

ADD DEVICE AND CONNECT WIFI

Special Attention :

1. Because this clock can't be connected to 5GHz WIFI network, so please set the router to 2.4GHz WIFI network first before you connect APP with the clock.
2. Please turn on **both** WIFI and Bluetooth on your mobile phone.

Method 1 :

1. Auto pop-up window to connect (Fig. 13).




Fig. 13



Fig. 14




Fig. 15

ADD DEVICE AND CONNECT WIFI

2. Enter the WIFI account and password that your phone is using to connect to the clock (Fig. 14).

3. Connection successful (Fig. 15).

Method 2 :

1. Click "Add Device" - "Add" and connect after the picture of **Children's alarm clock** device appears (Fig. 16)(Fig. 17).



Fig. 16



Fig. 17



Fig. 18



Fig. 19

ADD DEVICE AND CONNECT WIFI

- 2.Enter the WIFI account and password that your phone is using to connect to the clock (Fig. 18).
- 3.Connection successful (Fig. 19).

Method 3 :

- 1.Use the Smart Life APP to scan the QR code to connect (Fig. 20).
- 2.Enter the WIFI account and password that your phone is using to connect to the clock (Fig. 21).
- 3.Connection successful(Fig. 22).



Fig. 20



Fig. 21




Fig. 22

DEVICE RESET

Scenario 1 :

Enter the reset guide after accidentally entering the wrong WIFI password (Fig. 23)(Fig. 24).

Scenario 2 :

You can also scan the QR code directly with the Smart Life APP to see how to reset the device without opening the Bluetooth on your mobile phone (Fig. 25).




Fig. 23



Fig. 24



Fig. 25

DEVICE RESET

Attention :

Toggle the device WIFI icon fast flashing or slow flashing by holding SET button for 5s (Fig. 26).





Fig. 26

OPERATE CHILDREN'S ALARM CLOCK VIA SMART LIFE APP: MAIN INTERFACE



OPERATE CHILDREN'S ALARM CLOCK VIA SMART LIFE APP: FUNCTION SETTINGS

ALARM settings :

Set the name/volume/day of week/time of ALARM (Fig. 27).

SLEEP settings :

Set the name/volume/day of week/time of ALARM (Fig. 28).

LIGHT and SOUND settings :

Set the name/color/brightness/countdown of LIGHT (Fig. 29).

Set the name/ring tone/volume/countdown of SOUND (Fig. 30).



Fig. 27



Fig. 28



Fig. 29



Fig. 30

OPERATE CHILDREN'S ALARM CLOCK VIA SMART LIFE APP: FUNCTION SETTINGS

PLAY settings :

Set the time period of PLAY before WAKE (Fig. 31).

WAKE settings :

Set the name/day of week/time of WAKE (Fig. 32).

NAP settings :

Set the name/countdown/mode of NAP (Fig. 33).

TIME settings :

Select the device model. Set clock time in 12/24 hours mode. Synchronize the network time (Fig. 34).



Fig. 31

Fig. 32

Fig. 33

Fig. 34

Customer Service Number: 469-353-4385 (PST 8:00-16:00)

SMART LIFE APP CONNECTS TO AMAZON ALEXA

1. Download and login Amazon Alexa APP, and connect it with your Echo device (Fig. 35).
2. Enter the Smart Life APP and click “Alexa” (Fig. 36).
3. Click “Sign In With Amazon” (Fig. 37).




Fig. 35




Fig. 36




Fig. 37

SMART LIFE APP CONNECTS TO AMAZON ALEXA

4. Click “LINK” to connect Smart Life APP with Alexa (Fig. 38).
5. After Smart Life APP and Alexa connect successfully, click “Back” (Fig. 39).



Fig. 38




Fig. 39

ADD CHILDREN'S ALARM CLOCK IN ALEXA

1. Enter the Amazon Alexa APP and click “Add a Device” (Fig. 40).
2. Select “Light” (Fig. 41).
3. Scroll down to find “Smart Life” and click it to enter the next step (Fig. 42).
4. Then follow the step-by-step instructions until the connection is successful. After that, please enjoy the best life that smart Children's alarm clock brings to you (Fig. 43).




Fig. 40



Fig. 41



Fig. 42



Fig. 43

ALEXA PASSWORD

Turn on/off light :

Alexa, turn on/off light on the **Children's alarm clock**.

Alexa, is light on for **Children's alarm clock**?

Color of light : (The light must be turned on.)

Alexa, set **Children's alarm clock** to red/blue/purple/yellow/loop color.

Alexa, what is the mode on **Children's alarm clock**?

Turn on/off backlight :

Alexa, turn on/off backlight on the **Children's alarm clock**.

Alexa, is backlight on for **Children's alarm clock**?

Turn on/off child lock :

Alexa, turn on/off child lock on the **Children's alarm clock**.

Alexa, is child lock on for **Children's alarm clock**?

SMART LIFE APP CONNECTS TO GOOGLE HOME AND ADDS CHILDREN'S ALARM CLOCK

1. Download and login Google Home APP, and connect it with your Google Home device (Fig. 44)(Fig. 45)(Fig. 46).
2. Click “+”,Click “Set up device” (Fig. 46)(Fig. 47).




Fig. 44



Fig. 45




Fig. 46




Fig. 47

SMART LIFE APP CONNECTS TO GOOGLE HOME AND ADDS CHILDREN'S ALARM CLOCK

2. Select “Works with Google” (Fig. 48).
3. Scroll down to find “Smart Life” and click it to enter next step (Fig. 49).
4. Follow the step-by-step instructions until the connection is successful. After that, please enjoy the best life that smart Children's alarm clock brings to you (Fig. 50)(Fig. 51).



Fig. 48




Fig. 49




Fig. 50



Fig. 51

Customer Service Number: 469-353-4385 (PST 8:00-16:00)

WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body:
Use only the supplied antenna.

Please scan these QR codes below to watch the videos about how to finish setting.



TIME SETTING



ALARM SETTING



SLEEP SETTING



**PLAY-WAKE
SETTING**



**SOUND & LIGHT
SETTING**



NAP TIMER

Please scan these QR codes below to watch the videos about how to finish setting.



**CONNECT TO WIFI
DEVICE RESET**



**INTERFACE
UNDERSTANDING
AND CONTROL**



**FUNCTION
DEMONSTRATION**



**CONNECT TO ALEXA
& GOOGLE HOME**