



MIDOLA

USER GUIDE




B-15

*Know your B-15




1. Volume UP; Next Track
2. Power ON/OFF
3. Volume Down; Previous Track
4. 3.5mm AUX-in Port
5. Type-C Charging interface
6. Indicator Light
7. EQ Button
8. Built-in Microphone


*Power ON/OFF




*Volume Control




*Phone Call




*Pause/Play



*Music Control



*SIRI




*EQ Mode



Bluetooth

1. Pairing your device before the first use. Power ON the headphones and its Bluetooth mode is activated.
2. To pair the headphones with your mobile device. Turn on the Bluetooth on your smart phone, search and find "MIDOLA-B15" to connect. There will be a voice prompt after Bluetooth pairing successful.



* RESET



pls press and hold buttons of "-" & "+" at the same time for 5 seconds to reset the headphones

*Notice:

If cannot find any Bluetooth device in the effective range after 5 minutes, the headphones will be power OFF automatically.

AUX Input

No need to power ON the headphones. Plug the audio cable (included) into AUX-in port, plug another end of the cable into the output of the player i.e. phone/computer, etc.

Attention: Do not plug the Aux-in cable into 3.5mm Aux-in port when your headphones is power ON. Otherwise, your headphones will be turned OFF automatically

Charging

Plug the charging cable (included) into charging port, Plug another end of the cable into the AC adaptor(not included) or computer for charging

Indicator Light status
Charging: Red Light ON
Full Charged: Light OFF

*Notice

1. When playing music intermittently or shutdown automatically, please charge the headphones in time.
2. The headphone is designed to automatically power off while it is being charged. Therefore, it is recommended to turn off the headphone before initiating the charging process. This will ensure a smooth and efficient charging experience.

Specifications:
Bluetooth Version : V5.3
Working Distance : Appr. 10m
Impedance : 32Ω±15%
Speaker Size : Ø40mm
Frequency Response : 20Hz-20KHz
The battery capacity: 400 mAh
Charging time: Appr. 2 Hrs
Music Time: Appr. 70 Hrs
Talking Time: Appr. 70Hrs

Package Contents:

Headphones*1
Charging Cable *1
Aux-in Cable *1
User Manual *1

Battery Cautions:

1. The product is power by rechargeable battery. New battery performs better after two or three cycles of full charge and discharge. The battery can be recharged and discharge, but it will wear out.
2. Do not store it in over heat or cold places that may reduce battery capacity and life span. It is recommended to store it in 15 ° C to 25 ° C environment. It may not work in extreme cold or hot environment even it is fully charged.
3. Do not throw it into the fire to prevent exploding. Damaged battery may explode. Please follow the local regulations to handle the battery. Please recycle the battery as far as possible.
4. Please stop using it if there is a severe bulging. Do not use it after it soaked.

Tips:

Please regular recharge and discharge it every three months when unused for long time.

Precautions:

- Do not put the product in damp, dusty, oil smoke or steam environment, or expose to sunlight. Do not leave the product in vehicle for a long time, it may cause malfunction.
- Please adjust to proper volume, high volume may affect your hearing. For safety, please do not use the product while driving or bicycling.
- Do not use the product in the places where may become dangerous for sound cannot be heard, such as railway intersections, train stations, pedestrian crossings, and construction sites, etc.
- Do not place heavy objects on the product, it may cause deformation during long term storage.
- The accumulated static electricity in body may cause slightly tingle to ears, wearing clothes made of natural materials can minimize the effect.
- Do not excessively strike the product.
- Please use soft dry cloth to clean the product.
- Do not put the product into water. Headphones are not waterproof. Please observe the following precautions.
 - Beware of falling into sinks or other containers filled with water.
 - Do not use headphones in wet places or in bad weather, such as rain and snow.
 - Do not humidify the product. Touch the headphones with wet hands, or put the headphones in the damp clothes, which may cause malfunction.
- If feel uncomfortable when use the product, please stop using it immediately. If the problem persists, please contact the local dealer.
- If you have any questions about this product that do not include in the manual, please contact local dealer.

*FAQ for Bluetooth connection

Problems or Questions	Solutions
The headphones be turned off automatically in 5 minutes	Headphones be setted to be powered off if not connect with any Bluetooth device in 5 minutes,which for power saving purpose
The headphones will be paired with last Bluetooth device automatically in effective range upon headphones powering on	1)Power off your last Bluetooth device or remove the Bluetooth record from last device. 2)Power on your headphones again, and pair with new Bluetooth device
Could not find the pairing name on Bluetooth device	1)Clear those previous pairing names on Bluetooth device 2)Search Bluetooth devices to connect the headphones
Bluetooth couldn't connect	1)If have tried above methods and still could not connect,pls press and hold buttons of "-" & "+" at the same time for 5 seconds to reset the headphones 2)Search bluetooth devices to connect the headphones

Problems or Questions	Solutions
How to connect to 2 devices simultaneously?	1)Pair with your first device 2)Turn off the Bluetooth on the first device, then pair with the second device 3)Turn on the Bluetooth on the first device to connect again 4)Now your headphones are connected to the 2 devices at the same time
What type of device is compatible?	The headphones are compatible with all devices that support Bluetooth or 3.5mm plug cables. A wireless transmitter (not included) needs to be prepared when connected with a non-Wireless enabled TV/PC

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.