

DOUBLE SIDED

<div data-bbox="233 517 450 892"> </div> <div data-bbox="166 944 518 1029"> <p>6</p> <p>Confirm that the network WiFi display is your 2.4GHz WiFi network, enter your WiFi password and click "Next".</p> </div>	<div data-bbox="613 504 830 850"> </div> <div data-bbox="552 875 901 1029"> <p>5</p> <p>Please press the lamp switch by 3 times (on-off-on-off-on) in the open state ,till the light flashing quickly, click the "Next" button on the page to start configuration.</p> <p>Reset the device first.</p> <p>If the light is blinking rapidly, pls skip the reset step:</p> <p>① Power on the device.</p> <p>② Turn on-off-on-off-on (Subject to the user manually).</p> <p>Note: please complete the network quickly.</p> <p>③ Ensure the light is blinking rapidly.</p> <p>within 3 minutes after resetting the device.</p> </div>	<div data-bbox="982 497 1226 920"> </div> <div data-bbox="938 944 1287 1029"> <p>4</p> <p>Select "Light Source(BLE+Wi-Fi)".</p> </div>	<div data-bbox="1399 545 1595 888"> </div> <div data-bbox="1324 944 1673 1029"> <p>3</p> <p>After logging in,click the "+" on the upper right corner of the page or select "Add Device" on the device list page.</p> </div>	<div data-bbox="1768 528 2009 872"> </div> <div data-bbox="1714 944 2063 1029"> <p>2</p> <p>Open the app and create an account by following the on-screen instructions.</p> <p>Please click the "Register" button to register if you downloaded it for the first time. If you already have an account, click the "Login" button.</p> </div>	<div data-bbox="2239 401 2347 628"> </div> <div data-bbox="2103 654 2452 1029"> <p>1</p> <p>Before opening the app,make sure your phone is connected to the 2.4GHz WiFi and BLE that your bulb will be placed on.</p> <p>Search for "FLSNT" in the App Store or scan the QR code on the package/manual to download and install the app.</p> <p>Thank you for choosing FLSNT Smart LED Bulb.This Quick Start Guide will help you with setup and installation.</p> <p>Package Includes:</p> <p>Smart LED Bulb</p> <p>Quick Start Guide</p> <p>Note: FLSNT Connect devices only work on a 2.4GHz WiFi and BLE</p> </div>	<div data-bbox="2496 1073 2832 1531"> <p>IMPORTANT NOTE:</p> <p>FCC Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment .This equipment should be installed and operated with minimum distance 20cm between the radiator& your body.</p> <p>This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.</p> <p>Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> </div>	<div data-bbox="2876 432 3211 554"> <h1>QUICK START GUIDE</h1> </div> <div data-bbox="2862 683 3228 729"> <h2>Smart LED Bulb</h2> </div> <div data-bbox="2876 833 3211 918"> <h1>FLSNT</h1> </div> <div data-bbox="2876 1081 3228 1251"> <p>— Reorient or relocate the receiving antenna.</p> <p>— Increase the separation between the equipment and receiver.</p> <p>— Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.</p> <p>— Consult the dealer or an experienced radio/TV technician for help.</p> </div> <div data-bbox="2876 1295 3228 1334"> <p>If you have any good suggestions,please share them with us.Thank you again for choosing " FLSNT " .</p> </div> <div data-bbox="2984 1354 3120 1491"> </div> <div data-bbox="2876 1524 3228 1576"> <p>Company: HANGZHOU HUOSHILIGHTING CO.,LTD Address: Room 1202, Maya Building, Nanyuan Street Hangzhou Zhejiang China 311100</p> </div>
<div data-bbox="166 1053 206 1082"> <p>7</p> </div> <div data-bbox="166 1090 518 1142"> <p>Your bulb will now be connected to the network. You can see the light bulb on the "Devices" page after setting up successfully.</p> </div> <div data-bbox="166 1201 518 1506"> </div>	<div data-bbox="552 1053 592 1082"> <p>8</p> </div> <div data-bbox="552 1090 901 1123"> <p>Click into the editing interface of the smart bulb,You can choose to control it through a third party.</p> </div> <div data-bbox="613 1162 830 1539"> </div> <div data-bbox="572 1552 867 1591"> <p>*Click on the third party app you want to use to view the instructions.</p> </div>	<div data-bbox="938 1136 1304 1180"> <h3>Voice Activation for Alexa</h3> <p>Make sure your Alexa is installed and set up first.</p> </div> <div data-bbox="938 1201 1287 1506"> <p>1.Open your Alexa app.</p> <p>2.Open the menu to search for Skills.</p> <p>3. Then search for "Smart Life". Tap "Enable" to enable the Skill.</p> </div> <div data-bbox="968 1278 1118 1461"> </div>	<div data-bbox="1324 1069 1673 1123"> <p>4.Enter the FLSNT APP account and password, then tap "Link Now" to link your FLSNT account to enable the Skill. Now you can start your smart home journey.</p> </div> <div data-bbox="1385 1155 1595 1286"> </div> <div data-bbox="1324 1330 1673 1382"> <p>5.Using the name you assigned your bulb,you can Alexa to turn on/off, dim or brighten and change colors of your lights.</p> </div> <div data-bbox="1324 1410 1673 1480"> <p>Ex:Alexa,turn on/off bedroom light. Alexa,set bedroom light to 50 percent. Alexa,set bedroom light to green. Alexa,set bedroom light to warm white.</p> </div>	<div data-bbox="1704 1051 2063 1095"> <h3>Voice Activation for Google Assistant</h3> <p>Make sure your Google assistant device is installed and set up first.</p> </div> <div data-bbox="1704 1116 2063 1526"> <p>1.Open your Google Home app.</p> <p>2.Click the + to add a new device.</p> <p>3.Then tap the plus sign in the lower right corner and search for "Smart Life".</p> <p>4.Find Smart Life on the list and open it, select the country where your FLSNT app account is located, enter your FLSNT app account and password, and tap "Link Now."</p> <p>Choose the room where your device is located, and then the skill will appear on the Home Control Devices list. Now you can begin your smart home journey.</p> </div> <div data-bbox="1734 1175 2049 1325"> </div>	<div data-bbox="2103 1082 2452 1103"> <p>5.Control your smart device with Google Home.</p> </div> <div data-bbox="2103 1123 2452 1260"> <p>Ex: Hey Google, turn on/off bedroom light. (Turn on/off the light or other device) Hey Google, set bedroom light to 50 percent. (Set the light to any brightness) Hey Google, brighten bedroom light. (Brighten the light) Hey Google, set bedroom light to red. (Set the color of the light, only color changing lights support this function)</p> </div> <div data-bbox="2103 1330 2452 1531"> <p>FCC Caution:</p> <p>Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> </div>	<div data-bbox="2496 1073 2832 1531"> <p>IMPORTANT NOTE:</p> <p>FCC Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment .This equipment should be installed and operated with minimum distance 20cm between the radiator& your body.</p> <p>This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.</p> <p>Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> </div>	<div data-bbox="2876 1081 3228 1251"> <p>— Reorient or relocate the receiving antenna.</p> <p>— Increase the separation between the equipment and receiver.</p> <p>— Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.</p> <p>— Consult the dealer or an experienced radio/TV technician for help.</p> </div> <div data-bbox="2876 1295 3228 1334"> <p>If you have any good suggestions,please share them with us.Thank you again for choosing " FLSNT " .</p> </div> <div data-bbox="2984 1354 3120 1491"> </div> <div data-bbox="2876 1524 3228 1576"> <p>Company: HANGZHOU HUOSHILIGHTING CO.,LTD Address: Room 1202, Maya Building, Nanyuan Street Hangzhou Zhejiang China 311100</p> </div>