

Manual

How to operate:

1. Please hold this Function key button for few seconds to put into pairing mode.
2. The Bluetooth cassette will start flashing blue light meaning it has gone into pairing mode.
3. Now go into your Bluetooth setting on your device and select “BT Tape” to pair.
4. After the success of pairing, blue light will be stable on to indicate it’s paired.

5. Select the music on your device and enjoy wireless music.

More instruction for each button’s function:

- 1) “-” function:
A: Press long to reduce the volume,
B: Click short to change to previous song;
- 2) “+” function:
A: Press long to add the volume;
B: Click short to change to next song;
- 3) “Multi-functional button” function:
A: Press long to turn on/ turn off;
B: Single-click to “PAUSE” or “PLAY”. Under Bluetooth mode, answer calls by single-click, after the call, single-click to hang up; the cassette player will play music automatically.
C: Double-click to switch over Bluetooth mode and micro SD TF Card mode. (Notice: When you double-click to change to Bluetooth mode, wait till this voice finish “Bluetooth mode has been on, Paired”, then click this multi-functional button shortly, it will continue to play; when double-click to Micro SD card, after change successfully, it will play directly, don’t need to do click);

POWER STATUS: (1) iTape Bluetooth Cassette Adapter's Power Status can be showed at your phone; (2): Bluetooth Cassette Adapter will power off in 10mins after disconnect with Bluetooth;

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.