

## Wireless Video Transmitter & Receiver Kit

**Notice:** connect receiver to monitor, and connect transmitter to rear camera. They are generally used as car backup camera system.

### Parameters:

Receiver/transmitter frequency: 5740MHZ  
Voltage: DC 12V;  
Video format: NTSC/PAL; Recommended use 12V  
Working TEMP: -10°C- +80°C RH  
Receiver sensitivity: -85Dbm;  
Working current: DC12V/300mA;  
AV OUT interface: RCA jack.

### Package List:

1 x Wireless Receiver  
1 x Wireless Transmitter  
2 x 5.8GHz antenna  
1 x Manual

**Warning:** Transmitter can supply power to camera, power input equals to output. If you supply 12V to transmitter, transmitter will supply 12V to camera.

Please do not supply high voltage (over 12V) to transmitter if your camera cannot withstands high voltage (over 12V).

Please check the voltage range of your camera before connecting it to transmitter.

### Transmitter:

Red jack: power output to camera  
Yellow jack: connect to camera video jack  
Red and black cable: power input positive and negative.



### Receiver:

Yellow jack: connect to monitor video jack  
Red and black cable: power input positive and negative.



#### FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.