



Vicsoon Night Light Bluetooth Speaker
User Manual

* Please read the user manual carefully to avoid any accidents due to incorrect operations before using the product and keep it with proper care.

5-year warranty & After-sales service

Please scan the QR code to enter our brand official website to get a 5-year warranty.

Phone: +1 877 4031898 Email: vicsoonace@gmail.com


Customer Service Team Provides 24-hour Service

If the product has functional defects, quality problems, missing parts or other problems, please feel free to contact us, our customer service team will respond within 24 hours.

1. Product Introduction

This night light Bluetooth speaker can easily connect with most Bluetooth-enabled devices within a 10m range. It comes with a super quality sound with the help of high power woofer and unique bass technology. By touching its top, you can adjust the brightness and color mode of the light. It's also an alarm clock. With a modern appearance and multiple functions, it's an ideal room decor which can bring joy and relax to your life.

2. Product Appearance



3. Operating Instructions

① Short press to play or pause the music, Long press to enter "sleep mode".

② Short press to choose "Bluetooth mode" or "SD mode".

③ Short press to raise the volume, Long press to select next song.

④ Short press to turn down the volume, Long press to select last song.

⑤ Short press to enter "sleep mode", Long press to turn on/off "power saving mode".

⑥ Short press to answer calls, Double press to end the last call, Press 5 seconds to disconnect and cancel Bluetooth pairing.

⑦ ON/OFF: Turn on/off the Bluetooth speaker.

⑧ Micro SD: Insert micro SD memory card to play music.

⑨ Type-C: Plug in the charging cable to charge the Bluetooth speaker, Charging red light on, Fully charged: green light on.

⑩ USB HOST: Insert USB flash disk to play music, Plug in the charging cable to charge other electronic device, (It is recommended to use it as an emergency power source, as charging reduces battery life.)

⑪ RESET: Reset switch, press with sharp tool to restore factory settings.

NOTE: When using a USB flash disk or SD card to play music, the song formats that can be read: MP3/WAV/WMA/FLAC.

4. Features

Bluetooth Mode	Super Quality Sound	Hands Free Call
HDR Light	Dimmable Warm Light	Timer Shutdown
Power Saving	Time and Alarm Clock	SD Mode
SD Mode	Mobile Power Source	Rechargeable

5. How to Connect Bluetooth

Short press and you will hear "Bluetooth mode". Then turn on Bluetooth on your digital device. After a short time, a connected IM-M05 will appear on the screen, then connect it. The connection is successful. Note that the speaker can only connect one device. Then Bluetooth is on, previously paired devices will connect automatically. Therefore, when you can't find speaker's Bluetooth, it is because it is on.

NOTE: When the mobile phone is connected to the Bluetooth speaker, please turn the volume of the mobile phone to the maximum to ensure that the volume of the Bluetooth speaker is high enough.

6. How to Adjust Light

① **Warm light mode**
Short touch the top of the night light to change the brightness of the warm light (low brightness, medium brightness, high brightness). Long touch to switch to RGB mode.

② **RGB mode**
Short touch the top of the night light to change the color. There are 7 color modes with red, blue, green, purple, yellow, cyan color and music light. The last color mode can dance with the rhythm of music.

7. How to Set Time and Alarm Clock

① Time setting button
Short press to choose 12 or 24-hour clock, Long press to enter "time setting mode" and short press keys to set the hour and minute, then short press to store.

② Alarm clock button
Short press to turn on the alarm clock, the alarm icon on the screen displays and the alarm time flashes, Short press again to turn off the alarm clock, the alarm icon on the screen disappears, long press to clear the setting time. Short press to set the hour and minute, then short press to select (A: only sound, A-L: only light, A+S: light and sound). Last, short press to store the time and short press to select.

③ **Snooze mode**
When the alarm clock rings, if you don't press any key after 3 minutes or you touch its top within 3 minutes, the alarm clock will enter "snooze mode", it will ring again after 5 minutes, repeat 3 times and turn off automatically.

8. How to Use Sleep Mode & Power Saving Mode

Short press to enter "sleep mode", the night light will automatically turn off after 15/30/60 minutes, Long press to enter "power saving mode", the icon displays on the screen, then the screen will turn off after 60 minutes, the night light won't turn off, short press any key to open the screen immediately, Long press to turn off "power saving mode", the icon disappears.

NOTE: It is recommended to use the power saving mode to reduce unnecessary power consumption and extend the battery life.

9. Product Specification

Name	Night Light Bluetooth Speaker
Type	Mobile
Material	Plastic Metal
Battery Capacity	3000mAh
Rated Power	10W
Frequency	70-24000Hz
Light Source	LED
Color Temperature	3000K-Warm White-850K
Product Dimension	5.1*5.1*4.94"

10. Safety Warning

① To avoid electric shock, the power supply must be turned off prior to performing maintenance and repairs on the night light.

② Note that the night light is only suitable for use above its recommended voltage range. Components use above the permitted voltage range could harm the night light.

③ To use this product safely and effectively, please clean and inspect it on a regular basis (every six months). To clean the night light, turn off the power first, then use a soft, dry cloth dipped in soapy water to wipe it down, do not use any other cleaning agents as they could damage or discolor the night light.

Made in China

