

RGB Controller Instructions

Specifications:

Voltage: 12V DC;

Current: 0.02A

Control mode: APP control mode and RF Remote control mode

I, APP Control Mode: --- APP Operation For RGB Light



1.Download the “Happy Lighting” App on a smart device by scanning The QR code on the controller or searching for it in the App Store.



NOTE: Android users may have “Enable Unknown Sources” unde App Settings/Security to see “Happy Lighting” in the App Store.

2.Go to the device’s Bluetooth settings and pair the device with the wireless Controller.


NOTE: if the RGB Daytime Running Light is not powered by the Indicator, the Running light can be turned ON/OFF through the Happy Lighting App



3. Once synced, the Happy Lighting App will control the Light functions.Explore the various colors and functions using the App.

II, RF Remote control mode: --- Remote control function For RGB Light

4 Button Wireless Remote



A: Short Press 1-14 Times:

- 1) Colorful fading
- 2) Colorful flash
- 3) Colorful jumping
- 4) Red / green fading
- 5) Red / blue fading
- 6) Green / blue fading
- 7) Purple / yellow fading
- 8) Red fading
- 9) Green fading
- 10) Blue fading
- 11) Yellow fading
- 12) Cyan fading
- 13) Purple fading
- 14) White fading

B: Short press to select music mode.

C: Button to change the Speed.

D: On/Off,

FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.