


KB260GCM

MINI numeric keypad

USER'S MANUAL

MINI numeric keypad



Keyboard Specification:

Wireless technology: 2.4GHz

Wireless distance: 10m

Size: 103*121*16mm

key number: 26

Rated Voltage: 3.7V-4.2V

Capacity: 240mAh

Charging time: 2 hours

Compatible with Windows 2000/XP/Vista/Win7/Win8/Win10

Product Features:

1. The Numlock function is independent of any other keyboards that are currently connected.

2. 2.4G wireless technology.

3. Extended 26-Key numeric keypad layout.

4. Contain "+", "-", "1/x", "1/y" easy to enter formula.

5. Contain Esc,Tab, Backspace and Delete Keys.

6. Contain a shortcut key to open the calculator.

7. Three currency symbols(\$,€,¥)by Fn key combinations.

8. Scissor lift key construction.

9. Ultra-thin compact design,easy to carry.


10. Built-in li-ion battery,rechargeable.

Fn Key Combinations Descriptions:

By simultaneously pressing the Fn key and another key,you can input three currency symbols(\$,€,¥).

fn

+




=

\$

fn

+




=

€

fn

+




=

¥

01

02



Charging the Device:

1. This keypad builds in rechargeable li-ion battery. Please get it charged before first usage.

2. Charge the keypad when the status indicator flashes in the upper left corner.

3. Connect the keypad to the computer or USB charger with the supplied Micro USB charging cable to charge the keypad.

4. Charging time ≤2 hours.

Installation:

1. Plug the receiver into the computer USB port.

2. Push the power switch on the keyboard to On.If the indicator does not flicker,please charge the keyboard first.

3. The keyboard will automatically match the receiver. Just a moment,you can finish the connection.

Troubleshooting steps:

1.Insert the USB receiver into another USB port of the computer.

2.If you were using a USB hub, try to connect the keyboard directly with your computer.

3.It would be better to plug it into USB ports locating on the back of the chassis instead of those on the front.


4.Check USB hub for foreign objects or dust

5.Unplug and reinsert the USB connector

6.Restart the computer.

Warm tips:

If you try all the troubleshootings and still not work, please feel free to contact us at support@prohavit.com and give us a chance to help you.



www.prohavit.com

03

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that

interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The device has been evaluated to meet general RF exposure requirements, the device can be used in portable exposure conditions without restriction