


# User Manual



EN

## Welcome:

Thank you for choosing this wireless product.To ensure optimum performance and safety, please read these instructions carefully before operating this product.It is strongly recommended you keep this manual for future reference.

## Issue? Let us help you right away!

Our goal is your complete satisfaction. That's why we offer you a satisfaction guarantee. If you have any issues at all , please reach out to us right away Sales@sz-deying.com

## Package Contents:

- 1 x Wireless Keyboard
- 1 x Wireless mouse
- 1 x User Manual

EN1•

## Systems the multimedia keys support:

	Icon	Description	Win	Mac	Remarks
1	▶	Play/Pause	○	x	
2	■	Stop	○	○	
3	◀◀	Prev Track	○	○	
4	▶▶	Next Track	○	○	
5	-	Volume-	○	○	
6	+	Volume+	○	○	

## Combined Keys:

FN+F1	🎵	Player	FN+F7	▶	Play/Pause
FN+F2	◀-	Volume-	FN+F8	■	Stop
FN+F3	◀+	Volume+	FN+F9	🌐	Internet
FN+F4	✖	Mute	FN+F10	✉	Mail
FN+F5	◀◀	Prev Track	FN+F11	💻	Computer
FN+F6	▶▶	Next Track	FN+F12	🔖	FAV

EN2•

## Keyboard Product Specifications:

- 1.Key Type:Crater switch keys
- 2.Battery Type:AAA battery
- 3.Multimedia functions
- 4.USB 2.0 interface,plug&play,no driver required.
- 5.Compatible with Windows OS(Windows 2000,XP,Vista,WIN7,WIN 8,Win10),Mac.
- 6.Operating Voltage: 1.5V(AAA)
- 7.Operating Current: ≦ 3mA
- 8.Sleeping Current: ≦ 50uA
- 9.Sleeping time:20 seconds
- 10.Keystroke Force:65-70gf
- 11.Key Path: 3.5mm
- 12.Key Life: More than 5 million times
- 13.Dimension:437\*200\*28mm
14. Weight: 553±15g

## Keyboard Instructions:

### Pairing Method

Make sure the distance between the keyboard and the PC is within 20cm.Take out the Nano receiver from the mouse and Plug it into USB port of the PC, it would pair automatically.The LED will flash then turn off.Now the pairing is successful

Note:If the Keyboard pairing is unsuccessful.Press and holding"Esc"+"Q"to re-connect.If the Mouse pairing is unsuccessful.Press and holding"right key+center key"to re-connect.

EN3•

## Keyboard Re-pairing Method:

1. Unplug the USB receiver
2. Plug the USB receiver to the USB port, keep the keyboard and USB receiver distance within 20cm, Press "Esc + Q" keep 5S right away, then the keyboard light will flash, it is successfully re-paired.
3. IMPORTANT NOTE: You must press and holding"Esc"+"Q" within 10 seconds after you Plug the USB receiver to the USB port.

## Functional Zone:

1. Press "Num Lock" button,the LED of "Num" will turn off and the numeric zone will change to functional zone.
2. Number"2","4","6","8"are for down,left,right,up direction.
3. Number"1","3","7","9"are for"End", "Page Down", "Home", "Page Up".
4. Number"0" is for"Insert".
5. Decimal point is for"Delete".

## LED Indicator:

Num Indicator:It will show Red color when the numeric zone is on and the functional zone is off.  
Low Power Indicator:The three LED will flash together for 8 seconds when the voltage is lower than 1.1V. This will happen when you wake up the keyboard after sleeping or when you turn it on again until you change the battery.

EN4•

## Wireless Mouse:

### Product Specifications:

1. Working Frequency:2.4GHz
2. Operation Voltage:1.5V
3. Battery Type: 1AA battery
4. Current Dissipation:1.5V-8-10mA
5. Standby Current:0.5~2.0mA
6. Sleeping Current:50uA
7. Sleeping time:20S
8. DPI Resolution:800/1200/1600
9. Working Distance:≧ 10M
10. Key Life: 3million
11. Dimensions: 115.7\*65\*37.6mm
12. Weight:62g±3g

EN5•

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that

interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The device has been evaluated to meet general RF exposure requirement, the device can be used in portable exposure condition without restriction