



Computer Keyboard SR-K801 Manual

Installation Guide

Getting started with wireless keyboard SR-K801

1. Open the battery cover, put into two AAA battery (Pay attention to the + and - of the battery) cover the battery cover back

2. Get the USB receiver in packaging box slot, put it into computer USB port, plug and play

IF the wireless K801 drop the code, try as below process.

1. Put off all your receivers on your computer.

2. Put into batteries.

3. Place the keyboard near the computer. Try to press "ESC"+ "=" more than 3 seconds. then left light is on.

4. Put into the K801 keyboard USB receiver. Then can use

Troubleshooting

Wireless SR-K801 Keyboard not working?

1. Check the receiver connection, try a different USB port on the computer.

connect directly to the computer and do not use a USB hub.

2. Check battery orientation or replace battery.

3. Remove metallic objects near the keyboard

4. Restart the computer

FN KEYS

To use, press and hold the Fn key, then press an F-Keys (Compound keys)

Composite key:

FN+F1 / F2=F11 / F12

FN+F3=Play the default music player

FN+F4=Back

FN+F5=Play / Pause

FN+F6=Forward

FN+F7=Computer mute

FN+F8=Volume down

FN+F9=Volume up

FN+↑=Page up

FN+↓=Page down

FN+←=Home

FN+→=End

Two indicator light:

Light on the left light "Num lock" open

Light on the right light "Caps lock" open

NOTE :

1. The keyboard can be used normally after turning off "Num Lock".
2. After turning on "Num Lock", you can use the numeric keypad
(displayed in the upper right corner of the button)
3. To use the multimedia button, please press and hold "Fn" first.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction