




单页尺寸：L100*W133mm



How to connect Smart Floor Lamp to Amazon Alexa



1. Launch Smart Life App, sign into your account and make sure Smart Floor Lamp is on the device list.
2. Minimize Smart Life App, then launch the Alexa App and sign in your Alexa account and make sure you have at least one Alexa smart speaker – controlled device installed like Echo dot, etc.

3. In the upper left corner of Home page, press the button to show APP Menu. Then select in the menu.




4. Type in "Smart Life" in the search and press the search button next to it.


- 10 -



7. Go back to Menu by pressing button, and then press .





8. In the Smart Home page, you can group your devices in different categories. Your Smart Life APP has now been paired with Alexa. Now you can control your Smart Floor Lamp through Alexa.




How to connect Smart Floor Lamp to Google Home

1. Launch the Google Home App and make sure Google Home speaker is installed. If not, please follow Google Home speaker installation instruction to complete the installation.

- 11 -




2. Once Google Home is installed, in the upper left corner of App Home page, Pressing button to show App menu. Then press "Home Control" in the menu.



3. After successfully linking your account, in the Google Home App you can see all your smart devices from your Smart Life App account. You can assign rooms for each device.

4. Now you can use Google Home to control your smart device, you can say like.



FAQ

1. What should I do if I can't turn off or turn on the Smart Floor Lamp?

--- Make sure your cellphone and the Smart Floor Lamp are connected to the same WiFi connection.

2. What should I do when the configuration fails?

--- Make sure the Smart Floor Lamp's Red light is flashing – Twice per second.

--- Make sure to connect your Smart Floor Lamp within a short distance of your internet router.

--- Check whether the available internet network has a frequency of 2.4GHz.

--- Check your internet connection is working properly.



3. How can I share devices with my family members?

--- Open the Smart Life APP, select "profile" > "Devices Sharing" > "Sent" select "Add Sharing", now you can share with your family members.


4. Can this APP be used on any type of mobile phone? Can I control the device from a distance?

--- Yes, the APP can work with both android & iOS systems. Once connected to the Internet, there is no distance limitation.

- 12 -



- 13 -



- 14 -

- 15 -

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.