


Remote control operation instructions



① Previous song ② Music pause ③ Reduce volume ④ Increase volume ⑤ Next song ⑥

Long press the power switch ⑦ Single point to restore the default EQ mode

⑧ Mode switch ⑨ Long press Bluetooth one button to disconnect G-: reduce the DB of high tone G+: increase the DB of high tone D-: reduce the DB of low tone D+: increase the DB of low tone

Three. Operation function description

1. Connect the power supply

Connect the speaker and check that there is no error. Insert one end of the DC 24V power adapter into the power interface of the speaker, and the other end into the universal mains socket of 110V-240V. After the speaker is powered on, the panel indicator light will be lit and the prompt sound will be broadcast.

2. Bluetooth connection

1. Turn on the Bluetooth function of the Bluetooth device (such as mobile phone), search and select the name corresponding to this speaker in the Bluetooth device list.
2. If you need to input the paired password, the default password is usually "0000". After a successful connection, you will hear a prompt sound from the speaker, indicating that the connection has been successful.

3. Volume adjustment

1. The speaker is equipped with "+" and "-" volume adjustment buttons. Short press can adjust the volume step by step, and long press can quickly increase or decrease the volume.
2. The volume of the speaker can also be controlled through the volume adjustment function of the Bluetooth device or the button on the remote control.

4. Playback control

1. Play/pause: Short press the switch button on the control panel to control the music play/pause button, which can control the audio playback and pause, long press to turn on/off.
2. Previous / Next: Short press the "<" and ">" buttons to switch to the previous or next song.
3. The buttons on the remote control can also be used to control the corresponding functions.

5, Remote control playback control

In addition to controlling the corresponding functions on the main button, the remote control can also adjust the sound effect, see the panel button description for details

V. Precautions

1. Before use, please confirm that the power supply voltage is consistent with the requirements of the speaker, and use the specified DC 24V power adapter.
2. Avoid using speakers in high temperature, humidity or dusty environment.
3. Do not place the speaker near magnetic objects for a long time, so as not to affect sound quality

and equipment performance.

4. When cleaning the speaker, disconnect the power supply first, and gently wipe with a soft dry cloth. Do not use chemical cleaning agent.
5. If the speaker is not used for a long time, please disconnect the power supply.

Frequently Asked Questions

1. Bluetooth connection failure: Ensure that the speaker is within the effective range of the Bluetooth device, check whether the Bluetooth function of the Bluetooth device is normally enabled, and try to repair it.
2. No sound output: Check whether the volume setting is muted or too low, confirm that the audio source is playing normally, and replug and unplug the power adapter.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.