

User Manual

Wireless Smart Glasses
FCC ID: 2A5HP-M04

Thank you for purchasing the weariQ Wireless Smart Glasses. Before using this product, please read this instruction manual carefully and follow the instructions during the usage process. We are not liable for injuries caused by misuse or neglect of the instructions. Please keep this manual for future reference.

Important Safety Instructions

Please read all the contents of this manual and operate the product according to the instructions.

- Read all the contents of this manual and operate the product according to the instructions.
- This product is only used to provide smart audio and call services.
- It is not suitable for children.
- Use this wireless / BT smart glasses only for the purposes described in this manual.
- Do not place or store the glasses in places where they may fall or be dropped into water.
- If you have any concerns about your health, consult a doctor before use.

1

- If you experience any discomfort during use, such as dizziness, nausea, eye pain or other uncomfortable symptoms, stop using immediately.
- Do not immerse the glasses in water or any other liquid to avoid damaging the electronic components.
- When not in use, turn off the glasses and store them properly. Avoid exposing them to high temperatures or humid environments for a long time.
- These glasses are designed for adults and for personal use only. Do not use the glasses as children's toys.
- When using the glasses, make sure they are firmly fixed on your head to prevent accidental dropping.
- Use the glasses correctly according to the instructions in this manual to avoid damage caused by improper operation.

Attention:
This product contains small parts, which may pose a choking hazard to young children. Keep the glasses out of reach of children.

2

SAVE THESE INSTRUCTIONS

About the Product

1. Specifications

Product Name: Smart Glasses
Distance: 50 ft
Music Playing time: About 7H
Call time: About 7H
Charging Voltage: USB DC5V


Charging time: 1.5-2H
standby time: About 200 hours
Battery capacity: 3.8V / 120mAh
Weight: 0.068 lbs
Size: L5.86 x W6.34 x H1.83 inch

2. Package Contents

1 x Wireless / BT Smart Glasses
1 x User Manual
1 x Storage Box
1 x Charging Cable
1 x Clean Cloth

3

3. Product Structure



4

Operation Instruction

1. Power on/off & BT pairing

- Press and hold the MFB button for 2 seconds to turn on the device. When turned on, the blue LED lights up for 1 second and the voice prompts 'Power on'. After turning on, the device enters pairing mode and the voice prompts 'Pairing'.
- Press and hold the MFB button for 2 seconds to turn off the device. When the device is turned off, the red LED will remain on for 1 second and the voice prompt will say "power off".
- Turn on the BT of the device to be connected, search for weariQ-01 to connect. After successful connection, the blue light flashes once every 5 seconds, and the connection voice prompts "connected"; Disconnect BT connection, re-enter pairing mode, disconnect voice prompt 'disconnected'.
- After the connection does not work for 1 minute, it enters standby mode, and the blue light flashes every 5 seconds during standby;
- After booting up, the wireless / BT smart glasses will automatically reconnect to the last connected BT device. If multiple phones have been connected and not unpaired, the wireless / BT smart glasses will synchronously reconnect to both phones.

5

there is no BT connection for 5 minutes, the glasses will automatically shut down

- Clear pairing information with mobile phone: Press and hold for 10 seconds while turned off until the blue light flashes twice, then turn off again to clear the pairing information with the phone. After clearing, it will not automatically reconnect to the phone.

Call mode

- One click the MFB button to answer phone call
- One click the touch area to reject phone call
- One click the MFB button to hang up the current call

Voice assistant

- Double-click the MFB button

6

Charging mode

- Charging time is about 1.5 hours, low battery alarm voice prompt "beep"
- Low battery alarm interval is a few seconds, red light flashes twice; The red light is on when charging, and the blue light is on when fully charged

Cleaning and Maintenance

1. Turn off the device before cleaning it. Use a soft cotton cloth dampened with mild detergent to wipe it clean.
2. Do not spray water on the device or submerge it in water or any other liquid.
3. Do not expose the device to direct sunlight or high temperature. If the device has not been used for a long period, please take out the batteries.
4. Do not disassemble the device by yourself. Otherwise, it may cause damage and void the manufacturer's warranty.

7

Smart Glasses Troubleshooting Guide

1. Product Connection Issues

Problem	Cause	Solution
BT Pairing Failure	BT is not enabled, the device is not in pairing mode, the distance for pairing is too far, etc.	Make sure the phone's BT is on. Bring the glasses closer to the phone and re-enter pairing mode to pair.
	Interference sources present, distance too far, incompatible BT versions, etc.	Stay away from interference sources. Keep the device within the effective range, usually 10 meters. Check if the phone's BT version is compatible with the glasses.
Device Not Recognized	Incorrect connection of the device, BT service anomalies, etc.	Reconnect the device. If ineffective, try restarting both the phone and the glasses to restore normal BT service operation.

8

2. Operation and Usage Issues

Problem	Cause	Solution
No Response on Power On/Off	Depleted battery, incorrect button operation, etc.	Charge the device and then try turning it on again. Ensure correct button operation, such as holding the power button for 2 seconds to turn it on.
Play/Pause Function Not Working	Incorrect operation mode, software conflicts, etc.	Confirm whether the current operation mode is correct, such as being in music playback mode. Try closing other apps that may conflict and then perform play/pause operation again.

9

3. Functional Characteristics Issues

Voice Assistant Wake-up Failure	Voice assistant not enabled, network connection issues, etc.	Check if the voice assistant is enabled in the phone settings. Ensure a normal network connection for the voice assistant to respond properly.
---------------------------------	--	--

9

4. Maintenance and Care Issues

Problem	Cause	Solution
Surface Scratches	Contact with sharp objects, improper cleaning methods, etc.	Avoid contact with sharp objects. Gently wipe with a soft dry cloth when cleaning. Do not use rough or corrosive cleaning agents.

10

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

11

FCC Caution:

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

12

Guarantee

Thank you for shopping with us! This product comes with a one-year warranty from the date of purchase. Warranty will be voided due to any of the following:

- (1) Damage by improper operation, such as improper components connection.
- (2) Negligence and damage because of transportation or other accidents.
- (3) Maintenance and modification without approval.
- (4) Other damage caused by force majeure, such as natural disaster, abnormal voltage, among others.
- (5) Damage caused by general use outside home (e.g. industrial and commercial use).
- (6) Aging, wearing and tearing caused by normal operation of the product without affecting the normal operation of the product.

13

A Dedicated Team Just For You



Every weariQ product is backed by a 1-year warranty and an award-winning customer service team. If you are in any way dissatisfied with a product you ordered, we'll exchange it, replace it or refund your money under the warranty. Simply email us the problem, and we'll take care of it.

Troubleshoot
Help you solve any issues with your device.

Product Knowledge
Answer questions about your device and best practices.

Initiate Returns
Provide instructions for replacements, returns and refunds.

Place New Orders
Help with placing orders online or via authorized resellers.

14

Get in Touch.
Email: support@weariq.net

Made in China

US Importer:
Amazing Impulse, LLC
7025 CR 46A Ste 1071-412
Lake Mary, FL 32746
US