


# REMOTE CONTROL STUNT CAR INSTRUCTION MANUAL

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

## PRODUCT LIST



Remote Control Car x1




Controller x1

## BATTERY INSTALLATION

**Stunt Car:** 1. Open the battery cover under the car, connect the rechargeable battery pack to the power socket into the battery compartment.  
2. Close the battery cover and tighten it with a screwdriver.

**Controller:** 1. Use a Phillips screwdriver to loosen the screws on the battery cover and open battery cover.  
2. Load two 1.5V AA batteries according to the positive and negative poles of the battery holder.  
3. Close the battery cover and tighten the screws.

## Remote Control Function Introduction



## Remote Controller Button Function Description

Power Button	Power on the remote control car to the "ON" position, at this time the lights flash, the car enters pairing mode. At the same time, switch the power switch of the remote controller to the "ON" position, the body lights are constantly on, and music starts playing to indicate a successful pairing. The car defaults to driving mode, and the functions can be normally controlled. If the connection is not successful, please repeat the above operations.
Forward/Backward	Press the forward button, car will move forward; press the backward button, car will move backward. Long press button of "Forward/Backward" and car will continue to move forward or backward.
Snake Mode	Press the snake mode button to enter the snake-like driving pattern. Then, press the "Forward" to make the car move forward in a snake-like pattern; press the "Backward" button to make the car move backward in a snake-like pattern. If you hold down the button without releasing, the car will continue to move forward or backward in a snake-like pattern.
Turn Left/Turn Right	Turn left button, the car will turn left, Turn right button, the car will turn right.
Move Left Horizontally	Long press this button to make the car move left horizontally. If you continue to hold the button without releasing the car will keep moving left horizontally.
Move Right Horizontally	Long press this button to make the car move right horizontally. If you continue to hold the button without releasing, the car will keep moving right horizontally.
Lighting/Spraying	Lights: Press the button briefly to turn off the lights, press the button again to turn the lights on. Sprayer: Long press the button to turn on the sprayer, long press the button again to turn off the sprayer.
Music/Automatic Demonstration	Music: Press the button to switch to the next song, press the button again to turn off the music. Automatic demonstration: Long press the button to enter the automatic demonstration mode with music playing. Long press the button again to stop and exit the automatic demonstration.
One-click Twist	Switch the remote control car between flat running or climbing modes.
Switch Button	Press the switch button, then press the left turn/right turn button to change to left rotation/right rotation mode. Press the switch button again, then press the button to change to left turn/right turn mode.

## FCC Compliance Statements

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.