



SETTING UP	SUPPORT	INSTALLATION
<p>1 Insert Cards & Power On When powered up, your m106 PRO router will broadcast Wi-Fi signal with the SSID: CSG-XXX</p> <p>After inserting cards, turn on the router by pressing the power button</p> <p>2 Connect via Wi-Fi Connect to the Wi-Fi called CSG-XXX, and input the default Wi-Fi password: last 8 numbers of the serial number - labeled "S/N" on the bottom label of the router.</p> <p>3 Set up Router Visit http://192.168.8.1 in your browser to set up your router; start by choosing your preferred language.</p>	<p>Support</p> <p>Repair / Reset If you cannot access the web-based setup page or cannot connect to the router, you can press the Reset button: <ul style="list-style-type: none"> Press and hold for 3 seconds, and then release to repair your network. Press and hold for 10 seconds, and then release to reset the router to factory settings. All user data will be cleared. </p> <p>Technical Supports</p> <ul style="list-style-type: none"> For more detailed and updated instructions, please visit our website www.connectcsg.com/m106pro/support For further questions, contact us via these methods: <ul style="list-style-type: none"> Email: support@thisiscsg.com Contact our support line at +1 800-613-2218 	<p>Installation</p> <p>Screw Fixed Mount</p> <p>1 Align the wall mount to the wall. Secure 2 screws through the wall mount holes into the wall.</p> <p>2 Attach the router to the wall mount.</p> <p>Warning: Please maintain a minimum distance of 20cm from the human body when using the product.</p>

GL·iNet	
深圳市广联智通科技有限公司	
产品名称	M106 pro 说明书
物料编码	505-1155
单位/比例	mm/1:1
尺寸	90x128mm±1mm
材质	128g铜版纸/彩色印刷/折页+哑胶
日期	ver.20250319