

**使用说明书**  
使用前请阅读使用说明书



- 取出并配对  
第一次使用时, 请同时取出左右两侧的耳机。  
耳机白灯与冰蓝灯交替闪烁, 耳机将自动配对。

注:

1. 请将蓝牙耳机和手机(或其他的蓝牙连接设备)的距离在1米的范围内,进行连接;
2. 确保耳机在关机状态,长按多功能键约3秒直到白/冰蓝灯慢闪,此时进入配对状态,等待连接;
3. 开启用户手机蓝牙功能(或其他蓝牙设备),并进行搜索或扫描,此时手机会搜索到附近所有的蓝牙设备,点击搜索到的耳机名称"AS1"配对连接后,耳机指示灯熄灭。

注：1. 当耳机开机后，3分钟内未与相应设备进行配对连接，便会自动关机；

2. 超出信号有效连接距离，3分钟内未与相应设备连接，耳机自动关机，提示音“嘟”四声。

- 充电盒充电: Type-C数据线插入充电盒充电接口, 数码管末位闪烁;
- 耳机充电: 左右耳机分别放入电池盒对应仓内, 白灯长亮, 充满后灯灭。

**单击**

音乐模式  
通话模式

播放/暂停  
接听/挂断

**双击**

左耳:音量减  
右耳:音量加

单耳使用时左 (或者) 右双击均为音量加

 X2

激活语音助手

长按左耳多功能键2秒激活语音助手，  
单耳使用时，长按(或右)耳2秒，均可激活语音助手

电话模式

长按左/右耳多功能键2秒电话拒接

电量指示：iOS系统及部分Android系统可在屏幕直接显示耳

当从充电仓取出后会自动开机配对,耳机未与无线设备连接或耳机未与无线设备取消连接状态下,分别对左耳机和右耳机连续五击多功能键,提示音“嘟”四声后,耳机自动关机后将双耳机放回充电仓,再将双耳机取出,双耳机会自动配对,完成后即可连接无线设备使用。

适用于以下情况:

A:双耳无法配对时,单边首击,双配对成功时。

B:使用单耳机分别连接不同无线设备时。

C:清除连接的所有无线设备时。

特别提示:

当单边耳机出现无声,或者无法配对时,请按以上恢复重置操作。

首次使用耳机，建议首次把耳机和充电仓先充满电再使用。

本产品仅支持IPX5生活防水，使用时避免产品进液体。

若长期使用本产品，建议把产品充满电后，再存放；后续应在3个月内充一次电。

## 护理及保养

耳机和充电仓使用一星期左右，用棉签或精密布清洁耳机和充电仓的预计，防止顶针上有污垢，造成充电接触不良。

禁止使用腐蚀性液体清洁本产品。

**Instruction manual**  
Read the instruction manual before use



● **Take it out and pair it**  
For the first use, remove the left and right sides at the same time of headphones. The white light of the earphones flashes alternately with the ice blue light, and the earphones will Automatic pairing.

Multi-function touch keys

Indicator light

Charging contacts

Type-C charging port

Charging case power indicator light

**Concentrate:**

1. Please connect the Bluetooth headset and the mobile phone (or other Bluetooth connected devices) within 1 meter;
2. Make sure the earbuds are powered off, press and hold the multi-function button for about 3 seconds until the white/light blue light flashes slowly, then enter the pairing state and wait for connection;
3. Turn on the Bluetooth function of the user's mobile phone (or other Bluetooth devices), and search or scan, at this time, the mobile phone will search for all nearby Bluetooth devices, click on the searched earphone name "A51" to pair and connect, and the earphone indicator will be off.

1. When the earbuds are powered on and are not paired with the corresponding device within 3 minutes, they will automatically power off.
2. If the effective connection distance of the signal is exceeded and the device is not connected within 3 minutes, the earbuds will automatically turn off and the prompt tone will be played four times.

- **Charging case:** The Type-C data cable is plugged into the charging port of the charging case, and the last bit of the digital tube flashes;
- **Earphone charging:** Put the left and right earphones into the corresponding compartment of the battery box respectively, the white light will be on for a long time, and the light will turn off when it is full.

**Click**



Music mode  
Play/Pause

Call mode  
Answer/End the call

**Double-click**



Left ear: Volume down

Right ear: Volume up

When using one ear, double tap left (or) right to add volume

**Press and hold for 2 seconds**



Activate the voice assistant



**Phone mode**



Press and hold the left/right ear multi-function button for 2 seconds to reject the call

Phone battery indicator: iOS system and some Android system directly display the earphone battery level on the screen

**Special Note:** When there is no sound on one earbud, or the pair cannot be paired, please press the above to resume the reset operation.

## Care and maintenance

FCC Caution.

(1) § 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

§ 15.21 Changes or modification warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

§ 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

According to § 15.247(e)(i) and § 1.1307(b)(1), systems operating under the provisions of this section shall be operated in a manner that ensures that the public is not exposed to radio frequency energy level in excess of the Commission's guidelines.