



ZT-RCS-2 Instruction



- RED TO +12V DC
- BLACK TO GND
- YELLOW TO MOTOR UP
- GREEN TO MOTOR DN
- BLUE TO MOTOR UP
- WHITE TO MOTOR DN

@ Operation Mode Option:

A: Automatic Operation

1. Jumper K1 on the PCB unconnected
2. Press "UP" one time, the motor going up, Blue & Yellow wires output; press "UP" second time, the motor stop working
3. Press "DN" one time, the motor coming down, White & Green wires output; press "DN" second time; the motor stop working
4. If press "DN" while the motor going up, then the motor will coming down immediately
5. If press "UP" while the motor coming down, then the motor will going up immediately

B: Manual Operation:

1. Jumper K1 on the PCB connected
2. Pressing and hold the "UP", Blue & Yellow wires output, the motor going up; release the button "UP", the motor stop working
3. Pressing and hold the "DN", White & Green wires output, the motor coming down, release the button "DN", the motor stop working

@ New Remotes Programming:

1. Open the controller box, pressing on the button on the PCB and the LED lighting
2. Pressing on any button of the remote till the LED turn off
3. Remote program success
4. 4 remotes available at most

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.