

Product introduction:

Ralink chip is a high performance, high speed, good stability, long distance wireless network card, so that your laptop or desktop computer can connect to the wireless LAN at home or office, so that you can easily enjoy the high-speed and stable wireless network in any corner.



System requirements

- Notebook or desktop PC with Pentium 1GHz or higher processor
- Windows 2000/XP/Vista/ Win7, MAC OS, Linux • High-speed USB 2.0 port

1. Software and driver installation »

1. Note: For correct operation, do not connect the wireless card to your computer before installing the software. If you have done so, please wait until the new hardware is found screen appears, click "Cancel", otherwise the installation process may be affected. Insert the attached installation CD into the drive, open the CD as shown

below, select the operating system that matches your computer, and then click the ring  setup.exe to install



2. Select "I accept the terms of the License Agreement" and click "Next"

3. Select "Install driver and Ralink Wireless Network Setup Program" and click "Next"



4. Select "Ralink Wireless Network Setup Program" and click "Next"



5. Click Install to install the NIC driver



6. Click Finish. The NIC driver installation is complete



2. Set the wireless connection of the NIC (connect to available wireless signals) »

(1) After the driver is installed, an icon  will appear in the lower right corner of the computer desktop,  which will become after the network card is inserted. At this time, double-click the icon, the following interface will appear. Click the "Zoom in" icon on the left picture to search for wireless signals, as shown below



2) Select the wireless signal you need to connect, double-click the signal to connect, if the signal has a password, the part in the lower left corner of the picture will appear, continuously click the icon  in the picture to connect, when

the part of input password in the picture, please enter the password and click  to connect.



3) After the selection, the information of the connected wireless signal will appear, and the connected wireless signal will be marked with a check box, as shown in the figure below. The driver icon on the computer will also turn green  . Here the wireless card connection Settings are complete, after the connection can be wireless Internet access.



FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types USB WiFi Adapter (M-5572N-PCBA) (FCC ID:2A5OQ-M-5572N-PCBA) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the body is 0.441W/kg and Simultaneous Transmission is 0.779W/kg. This device was tested for typical body-worn operations with the back of the handset kept 0mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 0mm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided