

# INSTRUCTION

Note: Please read the following instruction carefully before installation and keep it for future reference.

## SPECIFICATION:

Power Source: 85-265V/AC

Power: 5W, 7W, 9W, 12W

Power Frequency: 50/60Hz

Ambient Light:<15LUX

Time Delay:Min.15-30sec

Max.3min±30sec

IP Grade: IP20

Detection Moving Speed: 0.6-1.5m/s

Detection Range: 360°

Base: E26, E27, B22

Detection Distance: max.6m(<24°C)

Working Temperature: -20~+40°C

Working Humidity: <93%RH

Installation Height: 2.2-4m

Material: Plastic + Aluminium



## Installation Instruction

- 1) Switch off the power before the installation.
- 2) The wires must be joined safety.

## Changing the lamp

- 1) Switch the main switch off.
- 2) Remove the lamp after the lamp is cooled down.
- 3) Replace it with a new one.

Picture	Code	Power	Dia.
	HX-5F-A60-SEN y	7W	60mm
	HX-7F-A65-SEN y	9W	65mm
	HX-9F-A65-SEN y	9W	65mm
	HX-12F-A70-SEN y	12W	70mm

"y" means color temperature: 2700K, 4000K, 6500K etc.

## Caution:

- 1) Electrical installation should be done by professional person only.
- 2) Disconnect the luminaire from supply and wait until luminaire is cooled down, before replacement of the bulb.
- 3) Never touch the lamp during luminaire is switched on.
- 4) In any case of malfunction disconnect luminaire from supply immediately. Do not try to repair the luminaire yourself; repair should only be done by professional person or official service agent.
- 5) Luminaire is not intended for looping-in connections.
- 6) If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.

Made in China

## FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body