


折叠后尺寸：120x90mm

Instruction Manual

AM FM Radio with Bluetooth

MODEL:TD-62



CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN
WARNING: TO PREVENT THE RISK OF FIRE OR ELECTRIC SHOCK, DO
NOT REMOVE COVER. NO USER-SERVICEABLE PARTS INSIDE
REFER SERVICING TO QUALIFIED SERVICE PERSONNEL


The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated "hazardous voltage" within product's enclosure, which may be sufficient to induce a risk of electric shock to persons.

PRECAUTIONS

1. There may be electric shock dangerous when you don't operate or use this machine correctly, please strictly operate in accordance with its regulations. Except for the authorized repairing personnel, never open the back cabinet arbitrarily so as to avoid the dangerous of electric shock.
2. Please don't expose the unit under the rain or humid place, preventing from water and spray. Don't put anything which fill with liquid like vase etc above this unit.
3. Please don't press or bend the AC cord of the unit, in case of the copper inside the AC cord break and lead to open circuit.
4. When fall across thunderstorm or you don't use this machine for a long time, please do pull out the AC plug.
5. Please pull out the batteries when not use DC power supply, so as to avoid batteries electronic leak liquid corroding the radio.
6. Don't use the batteries combined with new and old, or different category. Please put the dumped batteries at the place where indicate by government to avoid environment pollution.

— 1 —

PARTS INTRODUCTION



1. Speaker
2. Frequency display panel
3. Power indicator
4. Function Switch(BAND/BLUETOOTH Selector)
5. Antenna
6. Handle
7. Battery door

— 2 —

POWER SUPPLY

1. **AC power supply**: Please connect the inlet of the AC cord with the socket jack and put AC cord plug into power socket on the wall.


2. **DC power supply**: Please open the battery door, and put into 3pcs 1.5V UM-1/ "D" size batteries, then close the battery door.

Note:

- On the safe side, please pull out the AC plug from power supplying before installing batteries.

IMPORTANT

This appliance can be operated with dry cells batteries. When replacing these batteries, or disposing of the appliance, take care to follow current regulations relating to their disposal. Please place them in a specially assigned location to ensure that they are disposed of safely in accordance with environmental protection requirements.



— 3 —

RADIO OPERATION

1. Rotate the Volume knob to turn on the radio, the red indicator light will be lighted on, you can adjust the volume by rotating the Volume knob.
2. Select the FM/AM with band selector. Extend the antenna to get a better signal.
3. Rotate the Tuning knob on the right side to select a channel, channel indicator stays red when a channel is properly selected.
4. If you don't want to disturb others, you also can choose the earphone to listen radio, just plug the earphone into the earphone jack.

Note:

- If you have bad reception, please extend the antenna and change the direction to improve the reception.
- Please be gentle with the tuning knob and AM/FM band selector, thanks.

BLUETOOTH OPERATION

1. Rotate the Volume knob to turn on the unit and set the Function Switch to BT position, the blue indicator light in the upper right corner will blink.
2. Turn on the Bluetooth feature of your audio device, search for "TD-62" and pair.
3. Once your device is successfully paired with the unit, you will hear a short confirmation sound from the unit.
4. Play and stream music from your device to the unit.
5. Rotate the Volume knob to turn off the unit

Note: Bluetooth version:5.1

— 4 —

SPECIFICATIONS

1. Voltage: AC:110V/60Hz
DC:4.5V(3x1.5V,D size)
2. Frequency range: AM:520-1710KHz
FM:87-108MHz
3. Unit size: 219(L)x87(W)x120(H)mm
4. Unit weight: 648g(without battery)

PACKAGE INCLUDES

1 x AM FM Radio with Bluetooth
1 x English manual
1 x AC power cord

— 5 —

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.