




OPERATING INSTRUCTION	PACKING LIST	DESCRIPTION
<p>All the instructions should be read carefully before operation and follow the instructions.</p> <ul style="list-style-type: none"> The speaker should be situated away from heat sources such as radiators, and not exposed to moist air or water. Place the unit on a stable place to prevent it from being fallen down. The speaker should be only connected to a power supply described in the operating instructions. The user should not attempt to repair the speaker if you are not professional. Disconnect the power cable from the outlet & switch off before cleaning the unit. Please only use soft cloth, no harsh abrasives or chemicals to clean, as they will damage the appearance. The power cable of the speaker should be unplugged from the outlet and power switch should be off when left unused for a long period of time. 	<p>PACKING LIST</p> <ol style="list-style-type: none"> 1. Speaker 1pcs 2. Microphone 2pcs 3. User Manual 1pcs 4. Stereo Audio 1pcs 5. USB Charging Cable 1pcs 	<p>DESCRIPTION</p>  <p>Schematic diagram</p>

Button Function	MICROPHONE DESCRIPTION	Note
<p>1. MODE: MODE button is the mode conversion (Bluetooth, TF card, U disk, LINE).</p> <p>2. Music/Orig: Short press the Music Original button is to cancel the original singer's voice.</p> <p>3. EQ: Short press the "EQ" mode button is six kind conversions of EQ effect (pop, rock, classical, bass, treble, standard).</p> <p>4. ▲▼ : Short press "▲▼", it will be PREVIOUS song .</p> <p>5. ► : Short press "► " to pause or play.</p> <p>6. ►►: Short press "►►", it will be NEXT song.</p>	<p>MICROPHONE DESCRIPTION</p>  <p>Schematic diagram</p>	<p>1. EQ: Frequency ranges which are 8 different frequencies respectively.</p> <p>2. A B : A:Short press the A key to skip frequency, long press to switch A/B microphone.</p> <p>Note</p> <ol style="list-style-type: none"> Please use the 5V/2A charger to charge, do not play music while charging. When the microphone is turned on, do not point the microphone straight to the speaker to avoid howling. <p>Product parameters</p> <p>Power output: 10W/+10W Frequency: 100Hz---8kHz Drive unit: 311*2 S/N: ≥75dB Lithium battery: 7.4V/1500mAh Material: Plastic Color box size: 35*10*195mm Quantity: 20pc/st Carton size: 870*540*400mm</p>

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.