

<div data-bbox="304 357 517 392" data-label="Section-Header"> <h2>Wireless Earphone</h2> </div> <div data-bbox="280 456 542 676" data-label="Image"> </div> <div data-bbox="342 708 474 754" data-label="Caption"> <p>BT31 User Manual</p> </div>	<div data-bbox="586 336 891 365" data-label="Text"> <p>• These instructions are for your safety. Please read through them thoroughly before use and retain for future reference.</p> </div> <div data-bbox="586 384 676 399" data-label="Section-Header"> <h3>PARTS INCLUDED</h3> </div> <div data-bbox="586 419 754 446" data-label="List-Group"> <ul style="list-style-type: none"> • Micro-USB to USB charge cable • User manual </div> <div data-bbox="586 475 640 489" data-label="Section-Header"> <h3>WARNING</h3> </div> <div data-bbox="586 497 887 668" data-label="List-Group"> <ul style="list-style-type: none"> • This device is waterproof. There is no problem with rain in your life, but please do not soak in water. • Please keep it out of small children reach, and stock against humidity and hot temperature. • Please remove the electronic parts from the helmet when the device would be detached. • Please keep the device against acidic, alkaline and cuspidal things. • Please do not disassemble, amend or alter device alone, and do not throw and drop it. • No naked flame sources, such as lighted candles, should be placed on the apparatus. </div> <div data-bbox="586 692 685 707" data-label="Section-Header"> <h3>BATTERY WARNING</h3> </div> <div data-bbox="586 719 878 748" data-label="List-Group"> <ul style="list-style-type: none"> • Please make sure the charging time is about 2 hours at the first time. </div>	<div data-bbox="916 336 1220 405" data-label="List-Group"> <ul style="list-style-type: none"> • Do not throw the device in a fire, battery may explode or leak. • The Helmet with the electronic core shall not exposed to excessive heat such as burning sun, fire or the like. • Do not replace the set-in rechargeable Li-ion battery alone. </div> <div data-bbox="916 434 969 448" data-label="Section-Header"> <h3>FEATURES</h3> </div> <div data-bbox="916 461 1220 643" data-label="List-Group"> <ul style="list-style-type: none"> • Fashion design, let music surrounding your life any time. • Hands free function, truly free your hand. • Set-in rechargeable Li-ion battery, long stand-by and working time. • Support power displaying on iPhone, easy to know when will be charged. • New waterproof structure design, supports the Siri intelligent voice control function of the iPhone4 and above, and supports android intelligent voice control function, convenient, quick and intelligent. </div> <div data-bbox="916 668 999 683" data-label="Section-Header"> <h3>SPECIFICATIONS</h3> </div> <div data-bbox="916 695 1167 740" data-label="List-Group"> <ul style="list-style-type: none"> • Frequency: 2.402GHz-2.480GHz • Range: 10-15 meters (depending on device) • Transmission distance of Microphone: ≤1 meter </div>	<div data-bbox="1245 333 1411 416" data-label="List-Group"> <ul style="list-style-type: none"> • Li-ion battery: 3.7V/1000 mA • Playback time: ≤30~40hrs • Playback time: ≤30~40hrs • Charging Voltage: 5V • Charging time: ≤5 hrs • Standby time: ≤300 hrs • Bluetooth name: BT31 </div> <div data-bbox="1245 442 1314 456" data-label="Section-Header"> <h3>STRUCTURES</h3> </div> <div data-bbox="1245 461 1272 475" data-label="Caption"> <p>Fig. 1</p> </div> <div data-bbox="1245 505 1545 724" data-label="Image"> </div>	<div data-bbox="1574 333 1704 347" data-label="Section-Header"> <h3>CHARGING THE HEADSET</h3> </div> <div data-bbox="1574 362 1879 475" data-label="Text"> <p>Note: the Device will need to be fully charged prior to initial use(approx. 2 hours).</p> <ol style="list-style-type: none"> 1. Connect the micro-USB end of the charge cable to the micro-USB port on the Cap(Fig. 1) 2. Connect the USB end of the charge cable to the USB port of the computer or adapter(not included), 3. The LED indicator (Fig. 1) will turn solid RED while charging and will turn off when fully charged. </div> <div data-bbox="1574 489 1821 518" data-label="Text"> <p>Note:the Device can not be music playing or call answering while it is charging.</p> </div> <div data-bbox="1574 557 1688 571" data-label="Section-Header"> <h3>Compatibility devices:</h3> </div> <div data-bbox="1574 598 1865 740" data-label="Image"> </div>
<div data-bbox="257 802 367 817" data-label="Section-Header"> <h3>USING THE HEADSET</h3> </div> <div data-bbox="257 831 562 871" data-label="Text"> <p>Power On Press the power button 3 seconds, the device will be sound reminder as "Power on".</p> </div> <div data-bbox="257 879 562 1075" data-label="Text"> <p>Pairing 1. Press the BUTTON 3 seconds with the sound reminder of "power on" and the sound reminder of "pairing", then seek the name of "Music Hat" to pair, the sound remind of "connected" seems paired successfully(set-in the password of "0000" if your device is 2.0 version.) 2. Automatically repair If your device is the latest recent paired device, the headset will be automatically re-paired with your device when the device open it again. 3. Automatically search The device will be automatically into pairing mode again once the paired device is off.</p> </div> <div data-bbox="257 1085 562 1125" data-label="Text"> <p>Broadcasting/ Pause Press button to pause the song, press it again to continue the song.</p> </div> <div data-bbox="257 1128 562 1169" data-label="Text"> <p>Upper song/ decrease the sound press "+" one time for upper song, continue press the button to decrease the sound.</p> </div> <div data-bbox="257 1177 562 1220" data-label="Text"> <p>Next song/ increase the sound Press "+" one time for next song, continue press the button to increase the sound.</p> </div>	<div data-bbox="586 802 665 817" data-label="Section-Header"> <h3>CALL ANSWER</h3> </div> <div data-bbox="586 836 900 1005" data-label="List-Group"> <ol style="list-style-type: none"> 1) Android smart phone: the cap will be alarming with "DONG, DONG..." while somebody calling. iPhone: the Headset will be alarming with phone calling music which is the same as the phone calling music in iPhone. 2) answer phone: press the power button one time to pick phone up. 3) Hang-up: Press the button again to hang-up. 4) Re-dial phone function: Press the button two times to redial the most recently phone number directly. 5) Phone number broadcasting: somebody call you, the device will sound broadcast the calling phone number, and the user will easy to know who calling. </div> <div data-bbox="586 1013 873 1054" data-label="Text"> <p>Power save mode The device will be off automatically after 5 minutes if no working device paired.</p> </div> <div data-bbox="586 1059 873 1115" data-label="Text"> <p>Low power warning The device will be with the sound remind of "power low" while is working, it seems the power not enough, need to be charged.</p> </div> <div data-bbox="586 1121 896 1165" data-label="Text"> <p>Power Off Press the button 3 seconds again, the device closed with the sound reminder of "power off", and the LED indicator off.</p> </div>	<div data-bbox="916 802 1008 817" data-label="Section-Header"> <h3>INSTALLING STEP</h3> </div> <div data-bbox="916 826 1211 987" data-label="List-Group"> <p>Step 1 Take out the part from the color box, and find out the two earphone, put the earphone into the both sides of the ear position via magic tape (reference, Fig. 2)</p> <p>Step 2 And then, put the suitable position, try to put the helmet on the head so that the device is on suitable position, you can modify the position by hand in order to well use it. (reference, Fig. 3)</p> </div> <div data-bbox="916 1018 949 1032" data-label="Caption"> <p>Fig. 4</p> </div> <div data-bbox="916 1011 1211 1224" data-label="Image"> </div>	<div data-bbox="1267 798 1485 948" data-label="Image"> </div> <div data-bbox="1245 962 1375 978" data-label="Section-Header"> <h3>Installation Diagram</h3> </div> <div data-bbox="1256 997 1525 1233" data-label="Image"> </div>	<div data-bbox="1588 804 1861 1042" data-label="Image"> </div> <div data-bbox="1574 1069 1715 1083" data-label="Section-Header"> <h3>DISPOSAL AND RECYCLING</h3> </div> <div data-bbox="1574 1099 1865 1171" data-label="Text"> <p>Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice. Attention should be drawn to the environmental aspects of battery disposal.</p> </div> <div data-bbox="1776 1204 1861 1230" data-label="Image"> </div>

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.