


Active Noise Cancelling Headphones

Active Noise Cancelling Headphones  
User Manual


COMPATIBLE |  Android  iPhone  iPad

Welcome to use  
Thank you for purchasing this product. Please read this manual carefully and keep it well before using the product.


Structural diagram



Wearing



Package contents



Bluetooth pairing

1. Turn on the bluetooth of the mobile phone, and place the mobile phone and headphones together within one meter.
2. Find "A999" in the Bluetooth device list of the mobile phone for pairing.
3. Voice prompts "CONNECTED". If the connection is not successful, please repeat the above steps to connect again.

Connect to two mobile phones via Bluetooth

1. Connect the headphones with the phone 1, then turn off the headphones and the Bluetooth feature of phone 1.
2. Turn on the headphones and make it enter pairing mode.
3. Connect the headphones with phone 2.
4. Turn on the Bluetooth feature of phone 1, select "A999" in the Bluetooth list.

Bluetooth headphones power saving mode

1. If the headphones are power on for ten minutes without bluetooth connection and the ANC switch is not turned on, the headphones will power off automatically.

Line-in Playback/Line-in Noise reduction


Use the standard 3.5mm audio cable to connect the headphones to your phone, computer and other devices to listen to the music in your device.  
If the headphones is connected via line in when the ANC switch is turned on, it will enter the line in noise reduction.

Power on/off

Power on: When the headphones is off, press and hold the "Play/Pause" button until you hear "Power on".  
Power off: When the headphones is on, press and hold the "Play/Pause" button until you hear "Power off".

Noise reduction function operation

Noise reduction on: Turn on the ANC switch, you will hear the beep "ANC ON" and the default noise reduction depth is 36dB.  
Noise reduction off: Turn off the ANC switch, you will hear the beep "ANC OFF".  
Noise reduction depth selection: long press "Play/Pause" button to switch the noise reduction depth.  
Beep "One" Noise reduction depth is 36dB.  
Beep "Two" Noise reduction depth is 26dB.  
Beep "Three" Noise reduction depth is 18dB.



Answer/Reject phone calls

Answering incoming calls: Click the "Play/Pause" button to answer an incoming call and click again to hang up the call.  
Rejecting incoming calls: Press and hold the button "Play/Pause" for 2 seconds to reject the call when it comes in.

Redial the previous call

Double click the "Play/Pause" button in Bluetooth status to redial the previous call.



Music control

Click "Play/Pause" button to control music pause while playing music, and click again to resume music playing.  
Three clicks of "Play/Pause" button to enter voice assistant mode when playing music.



Click "Previous/Volume+" button, switch to the previous song, long press to increase the volume.  
Noise reduction depth selection: long press "Play/Pause" button to switch the noise reduction depth.



Click the "Next/Volume-" button, switch to the next song, and long press to decrease the volume.  
Click "Next/Volume-" button three times switching EQ mode, there are four modes: rock, pop, classical and natural.



Technical parameter specifications

Bluetooth version: Bluetooth 5.0  
Bluetooth range: up to 33 feet (free space)  
Bluetooth transmission frequency: 2.4GHz-2.48GHz  
Protocol supported: A2DP, AVRCP, HSP, HFP  
Driving unit: 40mm  
Impedance: 32 ohms  
Frequency Response: 20Hz-20KHz  
Sensitivity: 105dB  
Noise reduction depth One: 36dB  
Noise reduction depth Two: 26dB  
Noise reduction depth Three: 18dB  
Battery capacity: 700mAh  
Standby time: 150 days  
Bluetooth music/talk time: about 50 hours  
Music/talk + ANC working time: about 25 hours  
LINE+ANC working time: about 8 hours  
Charging time: 2 hours  
Charging port: Type-C  
Input voltage/current: DC5V ≥500mA  
Working environment: -10°C-50°C, humidity: 0-95%  
Product size: 215\*45\*180mm  
Net weight: 275g

Charging instructions

1. Before the headphones is used for the first time, please charge the headphones completely.
2. Charging cable: Please use the included Type-C charging cable to charge the headphones, or it may damage the headphones.
3. Charger: If using a charger, the output requires 5V DC, >500mA.
4. Indicator display: The red light stays on during charging, and the red light is off when fully charged.

Note: Please forgive us for any change in technical specifications without prior notice.

Precautions for using headphones

1. If you have not used the headphones for a long time, please charge it before using it.
2. Do not use headphones to listen at high volume continuously. If you have problems such as tinnitus or hearing loss etc, please lower the volume or stop using it.
3. Please do not use headphones to listen to music, make or receive phone calls while driving to avoid distraction and danger.
4. Please place the headphones out of the reach of children to avoid the danger of improper use by children.
5. If you feel significant discomfort, irritation and other adverse reactions when using the headphones, please stop using the headphones immediately.
6. The headphones use a built-in non-removable rechargeable battery, please do not try to remove or replace the battery in the headphones.
7. We are not responsible for any personal damage to the headphones caused by disassembling the headphones and removing the battery etc.

Frequently Asked Questions

If there is no sound from the headphones

- Please check if the volume of the headphones is appropriate.
- Please check if the headphones is connected to the mobile phone successfully.
- Please check if the headphones is in the working range.

The headphones does not work well when making a call

- Please confirm whether the mobile phone is in an area with strong signal.
- Please make sure the headphones is within the working distance.  
(Note: The working distance of the headphones is 33 feet, and there should be no obstacle between the headphones and the mobile phone.)

**FCC Caution:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.