

# Wireless charger Kit-K012

## instruction manual

### Wireless Charger Kit-K012 User Guide

#### product description

This product is suitable for Tuozhu 3D printed DIY wireless charging desktop ornaments. It can achieve 15W wireless charging and is suitable for various brands of mobile phones, headphones and other wireless charging products. It also comes with motor drive function and LED breathing light.

Packing list: wireless charging motherboard, LED light board\*10, LED adapter board\*2, button board, N20 reduction motor, electronic wire\*3 .

#### Introduction to use

#### powered by

1. Charging compartment charging: Please use the data cable to connect the Type-C port of the wireless charging motherboard , plug in the power supply to provide power . Please try to use an 18W charger for power supply to achieve maximum power output.

#### Connection accessories

During assembly, connect the LED breathing light to the LED adapter board, and then connect the adapter board to the two 0.8mm pitch LED interfaces under the wireless charging motherboard with the included electronic wire. Then connect the key board to the 0.8mm pitch key interface in the middle of the wireless charging motherboard through the electronic wire, and finally insert the N20 reduction motor into the 1.5mm pitch socket below the key interface; after the assembly is completed,

switch the power switch to the required gear. Ready to use.

## Specifications

product name	Wireless charger Kit-K012
Operating temperature	- 20 °C ~ 60 °C
Input voltage	5V /9V/12V
charging port	Type-C USB

## Precautions

- 1: Do not drop the product . Placing heavy objects on it or subjecting it to external collision may cause product failure and damage;
- 2: Children must use this product under adult supervision ;
- 3: Do not let this product come into contact with any corrosive liquid or use any cleaning liquid on it. When the product is dirty, please do not rinse it directly with water. Please use a soft dry cloth to clean it. Pay attention to keeping the surface of the product and the place where it is connected to the power supply dry;
- 4: Avoid covering wireless charging and charging equipment to affect heat dissipation during use ;
- 5: Please do not disassemble or modify, install it correctly according to the user guide to use this product safely ;

## FCC Requirement

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. This device should be installed and operated with minimum distance 20cm between the radiator & your body.