

FURINE

WIRELESS GAMING HEADSET




MODEL:X07

Device	Wireless (2.4GHz & BT5.0)			Wired (3.5mm audio jack)		
	Sound	Mic	Button Function	Sound	Mic	Button Function
Desktop	✓	✓	✓	✓	✓	×
Mac	✓	✓	✓	✓	✓	×
Laptop	✓	✓	✓	✓	✓	×
Tablet PC	✓	✓	✓	✓	✓	×
Mobile Phone	✓ (only BT5.0)	✓ (only BT5.0)	✓ (only BT5.0)	✓	✓	×
PS4/PS5 Console	✓ (only 2.4GHz)	✓ (only 2.4GHz)	✓ (only 2.4GHz)	✓	✓	×
PS4/PS5 Controller	×	×	×	✓	✓	×
Xbox Console	×	×	×	×	×	×
Xbox Controller	×	×	×	✓	✓	×
Switch	✓	×	×	✓	×	×


Package Contents



FURINE Wireless
Gaming Headset



2.4GHz Wireless
Transmitter



User Manual




3.5mm Audio Cable




USB Charging Cable
(Adapter not included)

Overview



Button Function



Power Button	Press button 1 time	Pause / play sound
	Press button 2 times quickly	Switch 2.4GHz & BT5.0 connection
	Hold button for 3 seconds	Power on/off
Mic Mute Button	Press button 1 time	Mic on/off
	Press button 2 times quickly	Switch gaming & music mode
	Hold button for 3 seconds	RGB light on/off
Volume+ Button	Press button 1 time	Volume up
	Hold button for 3 seconds	Play last song
Volume- Button	Press button 1 time	Volume down
	Hold button for 3 seconds	Play next song

Note:

1. Permanent hearing damage can occur if a headset is used at high volumes for extended periods of time.
2. Turn on the microphone by default after power on.
3. Press the power button and volume+ button simultaneously, after hearing the "disconnected" voice prompt, the headset will disconnect from the connected devices, and you could re-select the other device to connect.

Status LED

HEADSET	LED
Searching	Blinking light
2.4GHz connected	Solid white light
BT5.0 connected	Solid blue light
Low battery	≤ 5% battery: Flashing light


Microphone	LED
on	Solid orange light
off	off

Note:

1. If the headset is disconnected from your devices and no operation is performed for 10 minutes, the headset will turn off automatically.
2. After connected with your devices, if no operations are performed, the headset will turn off after 10 minutes.
3. Insert the 3.5mm audio cable, then the headset will enter into the wired mode.
4. In wired mode, the RGB light and buttons cannot be operated.
5. In wired mode, the microphone will automatically turn on, and only unplugging the mic can turn off the microphone.
6. In wireless mode, unplugging the mic or pressing the mic mute button one time can turn off the microphone.
7. Low Battery Reminder: When you hear the low battery tone 'battery low' and the indicator light flashes, please charge the headset in time.

Charging

It is recommended to fully charge the headset before first use.



CHARGE STATUS	LED
Fully charged	off
Charging	Solid red light

Note:

1. Please charge the headset with 5V/1A standard adapter;
2. Generally, it takes 4 hours to fully charge the headset, but the actual charging time depends on your charging devices;
3. The headset couldn't turn on while charging.


Using with PC/Mac in Wireless Mode




Transmitter
connection



1. Connect the 2.4GHz Wireless Transmitter.
2. Power on the headset.
3. When the status LED displays solid white or blue light, then the headset is connected.




1. Open sound settings.
2. Choose your output device 'X07'.




3. Choose your input device 'X07'.
4. FURINE X07 wireless headset can be used.

Using with PS4/PS5 Console in Wireless Mode



Route: Settings→Devices→Audio Devices
Set 'X07' as Input Device & Output Device


Using with PS4/PS5/Xbox Controller in Wired Mode



Note:

1. Insert the 3.5mm audio cable, then the headset turns off and enters the wired mode.
2. The microphone will turn on and the buttons cannot be operated in wired mode by default.
3. Wireless mode is not available for Xbox.

Using with Phone in BT5.0 Mode



Note:

1. If you want to go back to the 2.4GHz wireless mode, you can press the power button 2 times.
2. Frequent switching of modes will cause the headset connection to slow down.

Specification

Model	X07
Driver diameter.....	50mm
Speaker frequency response	20~20KHZ
Speaker impedance	32Ω
Battery parameter	3.7V/1200mAh
Working voltage	3.0-4.2V
Working current	70mA
Charging time	about 4 hours
Input charging standard	USB Type-C, DC 5V/1A
Mic sensitivity	-42 ± 3dB (Omnidirectional)
Wireless range	up to 65 feet (no obstacles between)

Troubleshooting



The microphone can not work

Wireless mode:

1. Check if you've set the headset as the default recording device;
2. Check if the microphone is turned off.

Wired mode:

1. Make sure the cable is connected tightly;
2. Microphones can not use when connecting to Some PC in wired mode. May require a 3.5mm 4-pole to mic/stereo splitter adapter (not included).



No sound or intermittent sound from the headset

1. Check if there are other obstacles that affect the transmission.
2. If intermittent sound occurs when you are communicating, please check if the network works smoothly;
3. Check if you've set the headset as the default recording device;
4. Check if the headset is in lowest volume setting.



Can't connect to devices

1. Check if you used a USB Extension or a USB Hub (it is not recommended);
2. Plug directly into the USB jack of the device's host;
3. Try to Replace a USB jack (some USB jacks may be power shortage);
4. For PC, it is recommended to plug into the USB jack at the back of the host;
5. Observe the indicator light and check if the headset is already connected with other devices.



Can't connect to devices in BT mode

1. Check if both the headset and your device open the BT mode, try to reduce the middle distance, and reconnect again.
2. Double press the power button to switch to the BT mode.
3. After power off, press and hold the power button for 7 seconds, the headset will clear the connection records and shut down. Delete the connection record of the headset in your device and reconnect the headset to your device again.

Questions or Setup Issues?

Contact the customers support team at
furineservice@gmail.com

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that

interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The device has been evaluated to meet general RF exposure requirements, the device can be used in portable exposure conditions without restriction