

# S01-3英文说明书

# 封面



## PRODUCT SPECIFICATION

Input: 9V/2A  
Phone Output: 15W10W/7.5w/5W  
Earbuds Output: 3.0W  
iWatch Output: 2.5W  
Input socket: Type-C  
Transmission Distance(Phone): <=8mm  
Conversion Rate(Phone): >73%

## PACKING LIST

- 1 x Wireless Charger
- 1 x Type-C Quick Charge Cable
- 1 x User Manual
- 1 x QC3.0 Adapter

## FAQ

1. If you're experiencing interrupted or slow charging, check the following:

- (1) The back of your phone should not have any metal, pop sockets, or credit cards.
- (2) Put the phone in the center of the charging surface (this lets the charging coil in your phone lineup with the one inside the wireless charger).
- (3) The wireless charging coil on Sony phones is located slightly below center.
- (4) Phone cases should be no thicker than 5 mm for effective charging.
- (5) Check whether the adapter is QC3.0 fast charger.

2. If you're failing to charge your device, please try out the following

If you are failing to charge your device, please try out the following steps:


- (1) Please restart your cell phone and test with other USB cables
- (2) Please check whether the indicator turns on or not.
- (3) The wireless charging coil on Sony phones is located slightly below center.
- (4) Phone cases should be no thicker than 5 mm for effective charging.
- (5) Check whether the adapter is QC3.0 fast charger.

## PRODUCT DESCRIPTION



## HOW TO USE

1. Plug in the Type-C cable to power on the wireless charge.
2. Put on your Qi enable devices to start charging.



## LED INDICATOR

LED status	Power On	Charging	FOD
LED Light	Green flashing and then disappear	Always green	Green Flashing

## APPLICABLE DEVICES

- 1. Smart Phone:**
  - ① Apple: iPhone 13, 13 Pro/13 Pro Max, 13 mini, iPhone 12, 12 Pro/12 Pro Max, 12 mini, SE, 11, 11 Pro, 11 Pro Max, Xs, Xs Max, XR, x, 8, 8Plus;
  - ② Samsung: Galaxy S: 22 5G,22+5G,22 Ultra 5G, 21 5G,21+5G,21 Ultra 5G, FE 5G,20 5G,20+5G,20 Ultra 5G,10,10+,10e,9,9+,8,8+,77 edge,6,6edge,6 edge, 6 G9209, 6Active; Galaxy Note:10,10e,10+,9,8,7,6,5;
  - ③ LG:G2(VS980, Verizon version),G3,G6,G6+,G7,G7 ThinQ,G7+ThinQ,G8, G8 ThinQ,V30/V30+,V35/V40 ThinQ,V50/V50 ThinQ, LG Lucid2(VS870), LG Optimus F5(As870), LG Optimus u3, Specirum 2, OptimusG Pro, OptimusVull, OptimusLTE 2, etc.
  - ④ MOTOROLA Droid Turbo, Droid Turbo2, Droid 5, Moto Maxx Ultra M, Moto XForce.(Note: All devices must meet the Qi standard).
- 2. Smart Watch: Apple: iWatch S7, S6, S5, S4, S3, S2, SE. (Only work for Apple Watch)**
- 3. Earbuds: Apple AirPods 2, AirPods Pro. Sumsung Galaxy Buds Buds+Buds Pro/Buds Live; Huawei Freebuds 2/3/4i/Pro; and more TWS(others Qi enable earbuds).**

#### FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

- measures:
  - Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.

## WARNING

1. Avoid using the product at places that are wet, humid or have high temperatures.
2. Avoid dropping the product from high places.
3. Do not disassemble the product by yourselves. Please contact us if necessary.
4. Do not clean the product unless the unit is powered off.
5. It is recommended to use 18W or above adapter to charge 3 smart devices at the same time.

