



65mm

65mm

## SPEAKER PRODUCT MANUAL



V1.0



- ① Press & Hold: Power ON/OFF  
Press: Play/Pause, Answer/Hang up, Search FM radio  
Double-Press: Switch Mode
- ② Press: Volume -  
Press&Hold: Previous song
- ③ Press: Volume +  
Press&Hold: Next song
- ④ Working Lamp
- ⑤ Microphone
- ⑥ Charging Light
- ⑦ Charge Port  
DC 5V
- ⑧ TF(Micro SD) Card

### DETAILED FUNCTION

- Power ON / OFF  
Press & Hold 'O' key: Power ON / OFF.
- Mode Switch  
Double-press 'O' key: Switch between BT / FM / TF card.
- Wireless Mode  
In BT mode, Open the phone BT function, select the product's pairing code, the speaker is connected after the success of sound.
- Phone Call / Handsfree  
When the speaker is in the BT connection status, if the mobile phone has an incoming call, the speaker will make a ringtone. Press the 'O' key to answer the call and press it again to hang up.
- TWS wireless couplet mode  
Open two speakers at the same time into BT mode, without BT

connection, short press any one of the 'O' keys to enter the couplet / disconnect couplet. After the couplet, use the phone to search and connect, you can play.  
(When TWS couplet mode, the two speakers automatically change to be left and right stereo, the TWS couplet mode only works in BT mode).

- FM radio mode
  - 1, Double-Press the "O" button to switch to radio mode";
  2. Plug the USB line plug into the speaker USB interface as an external antenna.
  3. Click the "O" button, enter the automatic search channel, after the search is completed, enter the first station broadcast play automatically.
  4. Press & Hold "+", "-" key to control the previous/ next channel
- TF card (Micro SD) Play Mode  
Insert the TF card, the speaker sounds, you can play music.
- Charge Battery  
Plug the USB cable into the speakers and connect the DC 5V charger or computer USB port to charge the speakers.

### INDICATOR LIGHT

Red: charging lit, red light goes fully charged.  
Blue Light: Flash: Bluetooth pairing; slowly: playback; Always: Play Pause.

### PRODUCT SPECIFICATIONS

Function: BT, Handsfree, FM radio, TWS, Card playback;  
Speaker:  $\Phi 40\text{mm}$ ,  $4\Omega 3\text{W}$   
Charge: DC 5V (USB)

### WARNING MESSAGE

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.  
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
NOTE: This equipment has been tested and found to comply

with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.  
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
-- Reorient or relocate the receiving antenna.  
-- Increase the separation between the equipment and receiver.  
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
-- Consult the dealer or an experienced radio/TV technician for help.  
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.