1. Description of Function

Power on	Long press the 3s remote control camera		
	button to turn on the device		
Reset key	In the event of an unexpected device crash,		
	pressing can restore the normal state		

2. Phone Pairing

Connect the Bluetooth remote control to the phone for up to 3 steps:

- 1. Long press the 3s remote control camera button to turn on the device:
- 2. Enable the Bluetooth function of the phone.
- 3. Search remote control on your phone and click Connect to pair successfully.

3. Indicator working status:

Charge	Red light
Low battery	Flash red light
Start up	Green light
Connection Failed	Green light
Connect Successfully	Flash green light
Full Battery	Green Light

4. Specification Parameters

Effective Range	10m
Lithium Battery	3.7V/90mAh
Charging Port	5V / 1A (Type-c)
Charging Time	1h
Compatible Device	Only the schutter button is available on
	mobile phones(Android, iOs, etc.)

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.