




THANK YOU FOR YOUR PURCHASE. COMPATIBLE WITH ANY DC 2.5-9V POWER SUPPLY. **ONLY USE AS INSTRUCTED BELOW.** DO NOT PLUG THE TRANSMITTER INTO ANY OTHER POWER SOURCE OTHER THAN AN OHMKAT POWER SUPPLY OR COMPATIBLE DC 2.5-9V SUPPLY. RECOMMENDED TO BE USED WITH OHMKAT POWER SUPPLIES FOR BUZZERS, ALARM SYSTEMS AND DOORBELLS THAT NEED A WIRELESS CHIME SOLUTION.

GENERAL INSTALLATION DIAGRAM



STEP 1: Unplug your OhmKat and open the split connection.

STEP 2: Plug the transmitter as in the diagram above.

STEP 3: Plug the chime into an outlet within 50-100 feet of the transmitter. Plug back in the OhmKat power supply.

STEP 4: Please ensure that your buzzer or doorbell is suitable to be used with an inline chime. If all is set correctly, chime will sound when buzzer or doorbell is pressed.

STEP 5: Test once your doorbell is powered up. If all sounds good, great. If the chime does not ring, please move it closer to the transmitter and try again. **To change default melody or volume, please re-PAIR the chime (see PAIRING instructions on right).** There are 32 different melody options. If your chime has a button (third button), you can choose sound+light, sound only, light only operation.

For any questions, please call (732-876-3034)
OR email (service@ohmkat.com)

WE LOVE HEARING FROM YOU!

DING DONG!

Your chime uses RF signal and does not need internet or WIFI. It is designed for long lasting service. You can pair additional chimes to same transmitter or re-PAIR for a different melody.

PAIRING instructions(also on our website):

1. Select the melody and volume level.
2. Press the volume button and hold it. You will hear two beeps. You are in pairing mode. Keep holding it down.
3. Ring the doorbell a few times (you will need a second person or an extension cord). You should hear 1 beep. It is paired.
4. Release the volume button. Test to confirm. Repeat 2&3 if needed.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that

interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment