

DR-58

User Documentation



1、Parameter

| Model | | Type | Headset |
|-----------------|-------------|----------------|-----------------------|
| wireless | V5.3+EDR | Protocol | A2DP, AVRCP, HSP, HFP |
| Frequencyrange | 2.4-2.4835G | TX power | Class B |
| CVCTMDSP | Support | Effective | 10Meter |
| FM Radio | Support | Frequency | 87-108MHz |
| MisoSD/TFCard | Support | Max support | 32G |
| Spaker material | NsFeB | Specification | 40mm |
| Sensistance | 105±34B | Distortion | ≤1%A t 1 KHz |
| Power ToBear | 30mW | Frequency | 20-20KHz |
| Resistance | 32 Ω | Recognition | Capacitance |
| Microphone | Support | Frequency | 30-16KHz |
| Sensitivity | 58±3dB | Recognition | Capacitance |
| Life time | ≥30hours | Chargeport | USBC |
| Standby time | ≥80 hours | Charge time | ≥2-3hours |
| Standby | 0.5-0.6mA | Charge time | 500mA |
| Battery type | Lithium | Charge voltage | 5V |
| Batery capacity | 400 mAH | Temperature | 15° CTo35° C |

2.Button,interface,switch

| | |
|---|--|
| M | Short press 'o' enter FM mode Short press twice to enter TF card mode |
| ▶▶/+ | Next song/volume+short press to increase the volume, long press a song |
| ◀◀/- | Previous/Volume- Short press to decrease the volume, long press the previous song |
| ▶ | Power on/off/oa/hang up function Short press on/short press off/long press on/long press off |
| Power on/double press the power on key to switch between Chinese and English | |
| The TF card is inserted into the TF card slot to play the MP3 past files stored in the card | |
| USB | Charging lint charger USB charging |

Be careful.
(Do not charge with a charging head exceeding 1.5A)

3. wireless

▶HSwitch, Hold down thr,The ▶Hheadset will then start. Light blue light and green light flashing in each other. Headset wirelessis on, Waiting for connection state. wireless headse this place at this time in the state can befind.
2)Click on the wireless Settings in the phone Settings, select *open'.This is opened Mobile phone wireless function.

3)Open the phone's bluetooth option, to find, search to waitfor matching success Bluetooth,shown on the list ofequipment available for DR58 click DR58 connection, at this time Headphones light flashing,saysit has the connectionis successful. Note: the partof the mobile phoneconnection, instructions Need to enter the password(0000).

3.1.TF Card Play

Insert: TP to headphones in the card slot, long press the M key switch to the crdread mode, indicatorlight,Flashing. Systen automatically decodedaudio format file, at thispoint your favor to melodious songs Gently.

3.2. Switch on/ hang up

Shortby answering the telephone, long press for 3 seconds to hang up the phone.

4.Charging

Befomcharging, the headset of, to make the charging line headset with computer USB connection.The headset indicator lightis red, the headset is charging.

The built-in battery capacity test and fire protection.Don't have to worry about charging time of the battery!Impact. Light automatically extinguished, said charging has been completed.

Low-power low battery automatically shut down,please charge as soon as possible, so as to meet the blueSystem re quirements.

Note:please don'topen he headset in the process of charging, therwise damage the headset battery hardeareLife.

5.Meters needing attention

1)this head sets not waterproof,please pay attention to wateroof and moistu proof, to ensure that the system can be positive Oten me.

2)it's the main support competer USB charging,don't change or connect it to the outside!charging power supply.

3)headst can not be placed for a long time, please charge and discharge once a week, so as to extend the electricity The pool of life.

6.To record the line connection phone listening to music, please turn off the power supply, lestcause noise.

If there is any problem with theproduct, or you have any questions, please contact us immediately, we will reply to you within 48 hours!

Contact Us: VIGOVITAC@163.com

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference received, including interference that may cause undesired operation.
 - (2) This device must accept any interference received, including interference that may cause undesired operation.
- Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment. The device has been evaluated to meet general RF exposure requirement.

This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter.

DR-58

用户文档



1、参数

| 型号 | | 类型 | 头戴式 |
|-------------|-------------|------|-----------------------|
| 蓝牙 | V5.3+EDR | 协议 | A2DP, AVRCP, HSP, HFP |
| 频率范围 | 2.4-2.4835G | 发送功率 | Class B |
| CVCTMDSP | 支持 | 有效距离 | 10米 |
| F收音机 | 支持 | 频率范围 | 87-108MHz |
| Mico SD/TF卡 | 支持 | 最大支持 | 32G |
| 扬声器材料 | 钕铁硼 | 规格 | 40mm |
| 灵敏度 | 105±3dB | 失真率 | ≤1%A t 1 KHz |
| 承受功率 | 30mW | 频率范围 | 20-20K Hz |
| 电阻 | 32 Ω | 识别 | 动圈 |
| 麦克风 | 支持 | 频率范围 | 20-16K Hz |
| 灵敏度 | -58±3dB | 识别 | 电容 |
| 播放时间 | ≥80小时 | 充电端口 | USB |
| 待机时间 | ≥180小时 | 充电时间 | ≥2-3小时 |
| 待机电流 | 0.5-0.6mA | 充电电流 | 500mA |
| 电池类型 | 锂电池 | 充电电压 | 5V |
| 电池容量 | 500 mAH | 工作温度 | 15° CTo35° C |

2. 按键、接口、开关

| | |
|------|---|
| M | 短按进入FM模式 短按两次进入TF卡模式 |
| ▶▶/+ | 下一首/音量+ 短按音量加大，长按下一首歌 |
| ◀◀/- | 上一首/音量- 短按音量减小，长按上一首歌 |
| ▶ | 开机/关机/接通/挂断功能 短按接通/短按断开/长按开机/长按关机 开机/双按开机键切换中英文 |
| TF卡槽 | 插入TF卡，播放卡内存放的MP3过去文件 |
| USB | 充电 链接充电器USB充电 |

注意.
(不要使用超过1.5A的充电头充电)

3. 蓝牙

▶H开关，按住▶H耳机将随之启动。指示灯蓝光与绿灯互交替闪烁。耳机蓝牙功能已经开启，正在等待连接状态。此时蓝牙耳机已处于可被查找状态。
2) 点击手机设置中的蓝牙设置，选择“开启”完成。这就打开了手机的蓝牙功能。

3) 打开手机上的蓝牙选项，进行查找，成功搜索到等待配对的蓝牙。可用设备列表上显示 DR58，点击DR58即可连接，此时耳机二指示灯闪烁，表示已经连接成功。注意：部分手机连接，指示需要输入密码（0000）。

3.1. TF卡播放

将TF插入到耳机卡槽中，长按M键切换至读卡模式，指示灯，闪烁不停。

系统自动解码可播放的音频各式文件，此时你钟爱约悠扬歌声轻轻响起。

3.2. 变通/挂掉

短按接听电话，长按3秒挂断电话。

4. 充电

充电前，关闭耳机电源，将充电线使耳机与电脑USB连接。此时耳机灯为红色，耳机正在充电。系统内置电池容量检测与过载保护，无需担心充电时可能对电池的影响。指示灯自动熄灭，表示充电已经完成。

电量低——电量低时会自动关机，请尽快充电，这样才能满足是蓝牙系统需求。

注意，充电过程中请不要打开耳机电源，否则损失耳机硬件电池寿命。

5. 注意事项

- 1) 这款耳机不防水，请注意防水与防潮，以确保该系统可以正常使用。
- 2) 它不支持电脑USB接口充电，不要改变或将其连接到外部其它电源充电。
- 3) 耳机不可以长期放置，请每周一次充电和放电，从而延长电池寿命。
6. 对求线连接手机听歌时，请关掉电源，以免引起杂音。

CC警告

该设备符合FCC规则第15部分的规定。操作要以下两个条件约束：

- (1) 该设备可能不会造成有害干扰，并且
- (2) 该设备必须接受接收到的任何干扰，包括可能导致不希望的操作的干扰。

注：根据FCC规则第15部分的规定，该设备经过测试，符合B类数字设备的限制。这些限制旨在提供合理的保护，防止住宅安装中的有害干扰。该设备产生、使用并可以辐射射频能量，如果不按照说明安装和使用，可能会对无线电通信造成有害干扰。

但是，不能保证在特定安装中不会发生干扰。如果该设备确实会对无线电或电视接收造成有害干扰，这可以通过关闭和打开设备来确定，则用户会感到干扰。