



**Blackview**

AceBook 6

USER GUIDE

## ■ Product Icon Graphic



## ■ Specification and Description

Model number	AceBook 6
LCD display	15.6" 1920*1080 16:9 LCD
Wireless network	802.11a/b/g/n/ac AC(Wifi 5) wireless network card, support bluetooth 5.0
Input and output ports	Audio interface: microphone input, headphone output 2 USB3.2 ports 1 USB2.0 port 1 Type-C port 1 HDMI port 1 TF-CARD card reader port 1 Headset
Audio equipment	Built-in high-definition audio equipment, dual sound channel Built-in dual stereo speakers
Memory card reader	Support TF-CARD
System status LED	Power switch, battery charging, camera working status
Keyboard	98 keys with 101/102 key emulation
AC power adapter	Input 100-240V AC 50/60Hz Output 45Wh Type-C PD
Battery	Polymer lithium battery
Indicator equipment	Built-in touchpad

## ■ Windows 11 Laptop Safety Instructions

Before using this product, please read the following guidelines carefully and follow these rules, which can increase the service life of the product, and can avoid the danger or violation of the law.

### 1. Battery safety

Please use the original batteries

#### **Warning:**

1. Using incompatible or third-party batteries may increase the risk of fire or explosion.
2. A damaged battery may cause personal injury (Note: damaged batteries such as deformation, fire baking, perforation, impact, etc.).
3. Do not decompose the battery.

#### **Note:**

Be extremely careful when handling damaged or leaking battery packs. If the battery is damaged, the electrolyte may leak from the battery and cause personal injury or fire.

### 2. Safety and regulatory information

1. Do not operate the equipment while removing any covers such as computer covers, bezels, filler brackets, front panel gaskets, etc.
2. Do not use the equipment in a humid environment to prevent liquid from flowing into the equipment.
3. Do not use damaged equipment, including cracked, broken, or damaged power cords.
4. Do not insert any objects into the ventilation holes or equipment openings. Doing so may cause fire or electric shock.
5. Do not place the base of the portable computer or adapter on the exposed skin for a long time while it is running. The surface temperature of the base will rise during normal operation, especially when using AC power. Continuous contact with exposed skin can cause discomfort or burns.
6. To disconnect all power from the portable computer, first turn off the computer, disconnect the AC adapter from the power outlet, and then remove all batteries installed in the battery bay or module bay.

### **3. Operate inside the equipment**

1. Harmful moving parts. Please stay away from rotating fans and blades.
2. The internal components may become very hot during normal operation. It should spare time to cool down before touching any internal components.
3. Disconnect all cables (including telephone lines) from the portable computer before opening the memory/modem baffle.
4. To avoid electric shock, please plug the power cable of the equipment into a properly grounded power socket, and use only the power cable approved for the equipment.
5. Make sure to keep new and used batteries away from children.

### **4. Power supply and adapter safety**

Please use the original power supply and adapter.

**Note:** AC adapters may be at high temperatures during normal computer operation. Ensure good ventilation and care should be taken when handling adapters during or just after operation.



Instagram



Facebook

Manufacturer: Shenzhen DOKE Electronic Co.,Ltd  
Address: 801, Building3, 7th Industrial Zone, Yulv Community,  
Yutang Road, Guangming District, Shenzhen, China.  
Website: [www.blackview.hk](http://www.blackview.hk)



Follow Blackview community, a place where you  
can share and discuss with Blackview user  
keep posted with most up-to-day news

# FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## Specific Absorption Rate (SAR) information:

This Laptop meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

## FCC RF Exposure Information and Statement

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: AceBook 6 (FCC ID: 2A7DX-ACEBOOK6) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use the body is 0.627W/kg. This device was tested for typical body-worn operations with the back of the Laptop kept 0mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 0mm separation distance between the user's body and the back of the Laptop. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

## Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 0mm must be maintained between the user's body and the Laptop, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.