



User Manual

MAGNETIC SPEAKER WITH PHONE STAND

PRODUCT SPECIFICATIONS

Wireless version: V5.3
Distance: 10m
Input power: 5V/1A
Battery capacity: 300mAh
Speaker power: 3W
Frequency response: 20HZ-20kHz
Product size: 66 x 56 x 41mm H
Function: Wireless, magnetic phone stand, TWS

PACKING INCLUDES

1 x wireless speaker
1 x instruction manual
1 x charging cable
1 x carabiner

WIRELESS SPEAKER

Long press button  to ON/OFF the speaker. Open your device (phone, pad etc) and search for "Bluetooth Name" to connect, once connected successfully, you will hear the sound "dengdeng", then you can start to playing music through the speaker.

TWS FUNCTION

1. Long press button  to ON two speakers.
2. Double press button  on one of them. After few seconds, two speakers will automatically connect when you hear "deng" sound.
2. Open your device and search for "Bluetooth Name" to connect, then you can play music through the speakers.

CHARGING

To charge your speaker, connect one end of the provided Micro-C cable to a USB power source. When the speaker is charging, the LED indicator light will illuminate red while charging and will turn off when complete.

This device complies with Part 15 of the FCC Rules. Operation is subject to the

following two conditions: (1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment