




5 in 1 clock Night Light Wireless Charger (foldable) User manual

I. Product Description

This device is a 5 in 1 clock night light wireless charger, compatible with Qi protocol mobile phone /Watch/TWS headset wireless charging. The night light and clock design is also very special and more practical.

This product adopts folding design, which is easier to store and carry. It can wirelessly charge multiple devices simultaneously. You can place the phone vertically or horizontally without affecting the phone's charging, and you can video chat or watch your favorite movies while charging.



II. Specifications

Name	5 in 1 clock Night Light Wireless Charger
Using Type	Foldable
Material	ABS+PC+ Aluminum alloy
Colour	Black/White
Charging Port	Type-C
Input Current	≥QC9V-2A,PD9V-2.22A
Phone Output	15W/10W/7.5W/5W
Watch Output	2.5W
Earphone Output	5W
Adapter	≥QC 3.0 18W(assorting)
Size	165*151*58mm
Compatibility	Support Qi Compatible Mobile Phone, TWS Earphones, Apple
Product List	Watch"Wireless charger x1, QC 3.0 adapter x1 (assorting) Type-C charging cable x1, manual x1

III. Operation Steps

1. Please firstly power on the device by our equipped QC 3.0 adapter and Type-C charging cable.
2. If the power is connected, the indicator lights up blue. When the wireless charger is in standby mode or the phone/watch is charging, the blue light is always on. The indicator light turns colored only when the headset is in normal charging mode.
3. When charging devices such as Q-enabled mobile phone, iWatch, or TWS Bluetooth Earphones, just place these devices on the corresponding charging area and they will be charged only after 0.1 second. When the devices are full charged or you want to terminate charging, just take them away from the charging area.

Put and charge when powered on



IV. Smart Indicator Light

1. The indicator of the standby mode is blue. When the mobile phone and headset are charging, the corresponding indicator is green.

2. It is recommended to use the equipped Quick charger 3.0 adapter (9V/2A).
3. The charging distance is 2-10mm, please don't wear protective case which is thicker than 5mm.
4. The watch has temperature control when the temperature reaches 45 degrees, which will stop charging automatically. If the temperature is normal, it will continue to charge.
5. The lower the temperature is, the faster charging speed is. The charging speed is faster in winter than in summer.
6. Please don't charge in high temperature and humid environment to avoid damage of circuit.
7. Put it at the place that children can't reach to avoid unnecessary accidents.
8. Please place the charger away from flammable and explosive liquids or gases.
9. Do not place magnetic cards, magnetic stripe media and precision machinery too close to the charge.
10. No metal or magnetic objects around 8mm of the back center of the phone during charging.


11. In the case of panel display, short press POWER key to turn off the display. Operation mode: Press and hold the M key to enter the time setting mode.

Step1: Short press the M key to enter the hour and minute setting, this is the hour of setting.

Step2: ↑ or ↓ button to adjust the time; ↑ button to adjust up (increase), ↓ button to adjust down (decrease).

Step3: Short press the M button to enter the minute setting, ↑ or ↓ button to adjust the minutes.

Step4: Press and hold the M button to exit the setting.



V. Notes

1. The indicator of the standby mode is blue. When the mobile phone and headset are charging, the corresponding indicator is green.

2. It is recommended to use the equipped Quick charger 3.0 adapter (9V/2A).
3. The charging distance is 2-10mm, please don't wear protective case which is thicker than 5mm.
4. The watch has temperature control when the temperature reaches 45 degrees, which will stop charging automatically. If the temperature is normal, it will continue to charge.
5. The lower the temperature is, the faster charging speed is. The charging speed is faster in winter than in summer.
6. Please don't charge in high temperature and humid environment to avoid damage of circuit.
7. Put it at the place that children can't reach to avoid unnecessary accidents.
8. Please place the charger away from flammable and explosive liquids or gases.
9. Do not place magnetic cards, magnetic stripe media and precision machinery too close to the charge.
10. No metal or magnetic objects around 8mm of the back center of the phone during charging.

11. In the case of panel display, short press POWER key to turn off the display. Operation mode: Press and hold the M key to enter the time setting mode.

Step1: Short press the M key to enter the hour and minute setting, this is the hour of setting.

Step2: ↑ or ↓ button to adjust the time; ↑ button to adjust up (increase), ↓ button to adjust down (decrease).

Step3: Short press the M button to enter the minute setting, ↑ or ↓ button to adjust the minutes.

Step4: Press and hold the M button to exit the setting.

FCC WARNING
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into a outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF exposure guidelines, this equipment should be installed and operated with a minimum distance between 2cm to the radio to your body. Use only the supplied antenna.

For Airpods Pro/3/2(wireless version only)/and more TWS Bluetooth Earphones with wireless charging case.
Operation mode: Press and hold the M key to enter the time setting mode.

Step1: Short press the M key to enter the hour and minute setting, this is the hour of setting.

Step2: ↑ or ↓ button to adjust the time; ↑ button to adjust up (increase), ↓ button to adjust down (decrease).

Step3: Short press the M button to enter the minute setting, ↑ or ↓ button to adjust the minutes.

Step4: Press and hold the M button to exit the setting.

For iPhone 15/15Pro/15Pro Max/14/14Pro/14Pro Max/13/13 Pro/13 Pro Max/13 Mini/12/12 Pro/12 Pro Max/11/11 Pro/Pro Max/X/XS/XS Max/XR/8 Plus.
For Samsung Galaxy S23/S22/S21/S20/10/10 Plus/10E/9/9 Plus/8/8 Plus/7/7 Plus/Note 10/Note 9/Note 8/Note 7/7/7 Edge/6/6 Edge/6 Edge Plus.

For Other Qi enabled Devices (Support wireless charging).

Step1: Short press the M key to enter the hour and minute setting, this is the hour of setting.

Step2: ↑ or ↓ button to adjust the time; ↑ button to adjust up (increase), ↓ button to adjust down (decrease).

Step3: Short press the M button to enter the minute setting, ↑ or ↓ button to adjust the minutes.

Step4: Press and hold the M button to exit the setting.

For Other Qi enabled Devices (Support wireless charging).

Step1: Short press the M key to enter the hour and minute setting, this is the hour of setting.

Step2: ↑ or ↓ button to adjust the time; ↑ button to adjust up (increase), ↓ button to adjust down (decrease).

Step3: Short press the M button to enter the minute setting, ↑ or ↓ button to adjust the minutes.

Step4: Press and hold the M button to exit the setting.

For Other Qi enabled Devices (Support wireless charging).

Step1: Short press the M key to enter the hour and minute setting, this is the hour of setting.

Step2: ↑ or ↓ button to adjust the time; ↑ button to adjust up (increase), ↓ button to adjust down (decrease).

Step3: Short press the M button to enter the minute setting, ↑ or ↓ button to adjust the minutes.

Step4: Press and hold the M button to exit the setting.

For Other Qi enabled Devices (Support wireless charging).

Step1: Short press the M key to enter the hour and minute setting, this is the hour of setting.

Step2: ↑ or ↓ button to adjust the time; ↑ button to adjust up (increase), ↓ button to adjust down (decrease).

Step3: Short press the M button to enter the minute setting, ↑ or ↓ button to adjust the minutes.

Step4: Press and hold the M button to exit the setting.

For Other Qi enabled Devices (Support wireless charging).

Step1: Short press the M key to enter the hour and minute setting, this is the hour of setting.

Step2: ↑ or ↓ button to adjust the time; ↑ button to adjust up (increase), ↓ button to adjust down (decrease).

Step3: Short press the M button to enter the minute setting, ↑ or ↓ button to adjust the minutes.

Step4: Press and hold the M button to exit the setting.

For Other Qi enabled Devices (Support wireless charging).

Step1: Short press the M key to enter the hour and minute setting, this is the hour of setting.

Step2: ↑ or ↓ button to adjust the time; ↑ button to adjust up (increase), ↓ button to adjust down (decrease).

Step3: Short press the M button to enter the minute setting, ↑ or ↓ button to adjust the minutes.

Step4: Press and hold the M button to exit the setting.

For Other Qi enabled Devices (Support wireless charging).

Step1: Short press the M key to enter the hour and minute setting, this is the hour of setting.

Step2: ↑ or ↓ button to adjust the time; ↑ button to adjust up (increase), ↓ button to adjust down (decrease).

Step3: Short press the M button to enter the minute setting, ↑ or ↓ button to adjust the minutes.

Step4: Press and hold the M button to exit the setting.

For Other Qi enabled Devices (Support wireless charging).

Step1: Short press the M key to enter the hour and minute setting, this is the hour of setting.

Step2: ↑ or ↓ button to adjust the time; ↑ button to adjust up (increase), ↓ button to adjust down (decrease).

Step3: Short press the M button to enter the minute setting, ↑ or ↓ button to adjust the minutes.

Step4: Press and hold the M button to exit the setting.

For Other Qi enabled Devices (Support wireless charging).

Step1: Short press the M key to enter the hour and minute setting, this is the hour of setting.

Step2: ↑ or ↓ button to adjust the time; ↑ button to adjust up (increase), ↓ button to adjust down (decrease).

Step3: Short press the M button to enter the minute setting, ↑ or ↓ button to adjust the minutes.

Step4: Press and hold the M button to exit the setting.

For Other Qi enabled Devices (Support wireless charging).

Step1: Short press the M key to enter the hour and minute setting, this is the hour of setting.

Step2: ↑ or ↓ button to adjust the time; ↑ button to adjust up (increase), ↓ button to adjust down (decrease).

Step3: Short press the M button to enter the minute setting, ↑ or ↓ button to adjust the minutes.

Step4: Press and hold the M button to exit the setting.

For Other Qi enabled Devices (Support wireless charging).

Step1: Short press the M key to enter the hour and minute setting, this is the hour of setting.

Step2: ↑ or ↓ button to adjust the time; ↑ button to adjust up (increase), ↓ button to adjust down (decrease).

Step3: Short press the M button to enter the minute setting, ↑ or ↓ button to adjust the minutes.

Step4: Press and hold the M button to exit the setting.

For Other Qi enabled Devices (Support wireless charging).

Step1: Short press the M key to enter the hour and minute setting, this is the hour of setting.

Step2: ↑ or ↓ button to adjust the time; ↑ button to adjust up (increase), ↓ button to adjust down (decrease).

Step3: Short press the M button to enter the minute setting, ↑ or ↓ button to adjust the minutes.

Step4: Press and hold the M button to exit the setting.

For Other Qi enabled Devices (Support wireless charging).

Step1: Short press the M key to enter the hour and minute setting, this is the hour of setting.

Step2: ↑ or ↓ button to adjust the time; ↑ button to adjust up (increase), ↓ button to adjust down (decrease).

Step3: Short press the M button to enter the minute setting, ↑ or ↓ button to adjust the minutes.

Step4: Press and hold the M button to exit the setting.

For Other Qi enabled Devices (Support wireless charging).

Step1: Short press the M key to enter the hour and minute setting, this is the hour of setting.

Step2: ↑ or ↓ button to adjust the time; ↑ button to adjust up (increase), ↓ button to adjust down (decrease).

Step3: Short press the M button to enter the minute setting, ↑ or ↓ button to adjust the minutes.

Step4: Press and hold the M button to exit the setting.

For Other Qi enabled Devices (Support wireless charging).

Step1: Short press the M key to enter the hour and minute setting, this is the hour of setting.

Step2: ↑ or ↓ button to adjust the time; ↑ button to adjust up (increase), ↓ button to adjust down (decrease).

Step3: Short press the M button to enter the minute setting, ↑ or ↓ button to adjust the minutes.

Step4: Press and hold the M button to exit the setting.

For Other Qi enabled Devices (Support wireless charging).

Step1: Short press the M key to enter the hour and minute setting, this is the hour of setting.

Step2: ↑ or ↓ button to adjust the time; ↑ button to adjust up (increase), ↓ button to adjust down (decrease).

Step3: Short press the M button to enter the minute setting, ↑ or ↓ button to adjust the minutes.

Step4: Press and hold the M button to exit the setting.

For Other Qi enabled Devices (Support wireless charging).

Step1: Short press the M key to enter the hour and minute setting, this is the hour of setting.

Step2: ↑ or ↓ button to adjust the time; ↑ button to adjust up (increase), ↓ button to adjust down (decrease).

Step3: Short press the M button to enter the minute setting, ↑ or ↓ button to adjust the minutes.

Step4: Press and hold the M button to exit the setting.

<