



# Smart Fish Tank User Manual

( Ver.3.1 )

## ■ Product Overview



Thank you for choosing our products. Please note that due to differences in selected packages and versions, there will be corresponding variations in product accessories. Before using the product, please refer to this instruction manual according to the actual product you purchased.

All the illustrations contained in the instruction manual are for reference only. In view of the continuous updates and upgrades of the product, there may be slight differences between the actual product and the schematic diagrams. Please refer to the actual product you received for a better user experience.

## ■ Touch Buttons

Make sure there is no water on the touch buttons to avoid abnormal touch functions.

Icons	Buttons	Operations
-------	---------	------------

	Feed	Press briefly once to feed
	Water Pump	Press briefly to turn the Water Pump on/off and circulate to filter the water quality in the fish tank.
	Oxygen Pump	Press and hold to turn the Oxygen Pump on or off to supply oxygen to the fish tank.(Optional accessory.)
	Light	<p><u>① Turn on the Lights</u></p> <p>When the lights are off, press briefly to turn on the lights. At this time, the lights will come on and be in the light switching mode state within 3 seconds. If there is no operation within 3 seconds, it will exit this mode.</p> <p><u>② Switch the Light Modes</u></p>

		<p>When in the light switching mode state, continue to press briefly to cycle through and switch the light modes.</p> <p><u>③ Turn off the Lights</u></p> <p>When the lights are on, press briefly to turn off the lights.</p>
--	--	--

## ■ Download the APP

- ① You can choose either the "XiaoMei Smart" APP or the "Leyu" APP.
- ② You can complete the APP download and installation process by scanning the QR code below or by searching for "XiaoMei Smart" or "Leyu" in the mobile application store.
- ③ Open the APP and enter the home page. Click on the "⊕" icon in the upper right corner and add the device according to the steps prompted by the APP. Since the APP will continue to be upgraded and

updated, the actual operation may be slightly different from the above description. Please refer to the real-time guidance within the APP.



(Scan to download the "XiaoMei Smart" APP)



(Scan to download the "Leyu" APP)

## ■ Parameter

Item	Parameter
Model	WP8689B
Dimension	301*138*182mm
Capacity	Approximately 5L
Input	DC5V/2A
Cable Length	1.5M
Output 1	DC5V
Output 2	DC5V
RGB Light Power	4.2W
Wireless Connection	Bluetooth
Compatible APP	XiaoMei Smart APP& Leyu APP
System Requirements	iOS 12.0 or above / Android 8.0

	or above
--	----------

Our company reserves the right to update and modify the product design specifications and the content of the instructions. In case of any changes, no further notice will be given!

## FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator and your body: Use only the supplied antenna.